

270 Select EX



Owner's Manual Part Number: MRP 1803645

WELCOME



Congratulations on becoming the new owner of the world's most prestigious boat. We at Sea Ray® Boats, Inc. welcome you into our worldwide and ever-expanding family of boating enthusiasts.

The Owner's Manual Packet, to be kept on board your Sea Ray, gives you important information on all the features of your Sea Ray. For years of trouble-free boating take the time to carefully review the information in your Owner's Manual Packet and really get to know your boat. Have everyone who will operate your boat read this manual.

The Owner's Manual Packet contains the following:

Owner's Manual

The Owner's Manual gives you important operating and safety information, as well as reminding you about your responsibilities as a boat owner/operator.

Original Equipment Manufacturer (OEM) Information

This section of your Owner's Manual Packet contains information from the manufacturers of equipment installed on your boat. Examples include the engine, engine control and steering system. Throughout the Owner's Manual you will be referred to information provided by manufacturers of specific systems.

Because your purchase represents a substantial investment, we know you will want to take the necessary measures to protect its value. We have outlined a program for proper operation, periodic maintenance and safety inspections. We urge you to follow these recommendations. If you have questions which are not fully covered by the Owner's Manual Packet, please consult your authorized dealer for assistance.

Thank You For Selecting A Sea Ray®!

Bon Voyage



THIS PAGE LEFT INTENTIONALLY BLANK

Introduction

1. This Manual

The material here and in the rest of the Owner's Manual Packet:

- Gives you basic safety information;
- Describes the features of your boat;
- Describes the equipment on your boat;
- Describes the fundamentals of boat use; and
- Contains service and maintenance information.

You must learn to operate this boat as well as read, understand and use this manual.

What this manual <u>does not</u> give you is a course in boating safety, or how to navigate, anchor or dock your boat. Operating a power boat safely requires more skills, knowledge and awareness than is necessary for a car or truck.

2. Your Responsibilities

For your safety, the safety of your passengers, other boaters and people in the water, you must:

- Take a boating safety course;
- Get instruction in the safe and proper handling of your boat;
- Understand and follow the "rules of the road";
- Learn how to navigate.
- Registration: In addition to the registration requirements for your boat in the state where it is used most frequently. Many states require additional registration when an out-of-state boat is used within their boundaries. Contact state boating authorities or any marine dealer for registration requirements.

3. Sources of Information

In North America, contact one of the following for boating courses:

- U.S. Coast Guard Auxiliary
- U.S. Power Squadron
- Canadian Power and Sail Squadrons
- Red Cross
- State Boating Offices
- Yacht Club

Contact your dealer or the Boat/U.S. Foundation at 1-800-336-2628

Outside of North America, contact your boat dealer and/or your governmental boating agency for assistance.

A book that provides a comprehensive background in boating is Chapman - Piloting, Seamanship and Small Boat Handling, by Elbert S. Maloney, published by Hearst Marine.

Introduction

4. DEALER RESPONSIBILITIES

In addition to a predelivery check and service of the boat, your dealer is to give you:

- A description and demonstration of the safety systems, features, instruments and controls on your boat;
- An orientation in the general operation of your boat;
- An "In Service Check List" form completed by you and the dealer after your inspection of the boat;
- A review of all warranty information and how to obtain warranty service;
- The complete Owner's Manual Packet.


If you do not receive all of these materials, or have any questions, contact your dealer or call: 1-800-SRBOATS.

5. WARRANTIES

Your boat comes with several warranties. Each component and/or system on your boat has its own warranty that will be found with the specific information and manual for that component. These are included with your Owner's Manual Packet. Locate and read the individual warranties; then put them together for easy future reference. The Sea Ray® warranty is on the warranty information sheet in your packet.

6. Hull Identification Number (HIN)

The "Hull Identification Number" located on the starboard side of the transom, is the most important identifying factor and must be included in all correspondence and orders. Failure to include it creates delays. Also of vital importance is the engine serial number and part number when writing about or ordering parts for your engine. Refer to the Engine Operator's Manual for location of engine serial number and record it for future reference.



Introduction

7. Manufacturer's Certification

As a boat manufacturer, Sea Ray builds their products to guidelines established under the Federal Boat Safety Act of 1971. The Act is promulgated by the United States Coast Guard who has authority to enforce these laws on boat manufacturers that sell products in the United States. Sea Ray ensures that all of its products comply with these laws.

The NMMA, National Marine Manufacturers Association, provides Sea Ray with a third party certification. The NMMA is an organization that represents the marine industry and assists manufacturers, boat dealers, marinas, repair yards and component suppliers in areas of legislation, environmental concerns, marine business growth and state and federal government agency interaction. The third party certification that Sea Ray participates in, uses the well know Standards and Recommended Practices of the ABYC, American Boat and Yacht Council.

Sea Ray Boats participates extensively in the American Boat and Yacht Council which is a nonprofit organization that develops and publishes voluntary standards and recommended practices for boat and equipment design, construction, service and repair. We utilize all applicable ABYC standards in the construction of your Sea Ray boat.

Finally, Sea Ray sells their products world wide and as such must conform to the various rules and regulations required by other countries. Most notably, are the ISO standards in Europe which require the application of the CE (Common European) mark. This mark, much like the NMMA certification here in the US, gives you the boat owner specific information concerning your craft. For more on this, turn to Section 1 • Safety, subsections 8 and 13 which explains in detail the CE plate and its importance.

8. SERVICE, PARTS AND REPAIR FOR YOUR BOAT

When your boat needs service, parts or repair, take it to an authorized Sea Ray® dealer. To find a dealer in your area call:

Domestic: 1-800-SRBOATS

Fax: 1-314-213-7878

(International: 1-314-216-3333) or on the Internet at www.searay.com

To find repair and parts facilities for the equipment installed on your boat, refer to the manual for that component.

If a problem is not handled to your satisfaction:

- Discuss any warranty-related problems directly with the service manager of the dealership or your sales person. Give the dealer an opportunity to help the service department resolve the matter for you.
- If a problem arises that has not been resolved to your satisfaction by your dealer, contact Sea Ray® Boats at 1-800-SRBOATS (International 1-314-216-3333) and the appropriate customer service department information will be provided to you.



Sea Ray offers an express Limited Warranty on each new Sea Ray purchased through an authorized Sea Ray dealer. A copy of the Limited Warranty was included in your owner's packet. If for any reason, you did not receive a copy of the Limited Warranty, please contact your local dealer or call 1-800 SR BOATS for a replacement copy. This is a summary of several provisions of the Limited Warranty. Please read the Limited Warranty, which is the controlling document.

Under the Limited Warranty, Sea Ray covers: (a) structural fiberglass deck or hull defects which occur within five (5) years of the date of delivery; (b) parts founds to be defective in factory material or workmanship within one (1) year of the date of delivery; (c) laminate blisters resulting from defects in factory material or workmanship for five (5) years on a prorated basis.

Sea Ray's obligation under the Limited Warranty is limited to repair or replacement of parts that are judged defective by Sea Ray and does not include transportation, haul out, or other expenses. The foregoing is the **sole and exclusive** remedy provided by Sea Ray.

The Limited Warranty does not cover engines, stern drives, controls, propellers, batteries, trailers, or other equipment or accessories carrying their own individual warranties, nor does the Limited Warranty cover engines, parts or accessories not installed by Sea Ray. The Limited Warranty does not cover cosmetic gel coat finish. Boats used for commercial purpose are excluded from coverage. See the Sea Ray Limited Warranty for other exclusions.

SEA RAY EXPRESSLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. NEITHER SEA RAY NOR THE SELLING DEALER SHALL HAVE ANY RESPONSIBILITY FOR LOSS OF USE OF THE BOAT, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS OR CONSEQUENTIAL DAMAGES.

The unexpired term of the Limited Warranty may be transferred to a subsequent owner upon the new owner's request. The new owner can submit a request for warranty transfer, free of charge, via the searay.com website. Alternatively, the new owner can submit a written request to the Sea Ray Division of Brunswick Corporation, 2600 Sea Ray Blvd., Knoxville, TN 37914, accompanied by a Fifty Dollar (\$50.00) processing fee.

Thank you for your decision to buy a Sea Ray.

The Sea Ray Limited Warranty is subject to change at any time at Sea Ray's discretion. The information contained herein is general information about the Limited Warranty for the owner's general knowledge, but does not alter or amend the terms of the Limited Warranty.

270 SLX Owner's Manual • Table of Contents

Introduction	22. Warning Label Locations 1.17
1. This Manual	iii
2. Your Responsibilities	iii
3. Sources of Information	Section 2 • General Boat Arrangement
4. Dealer Responsibilitiesi	V
5. Warrantiesi	1. Docking/Lifting/Storage2.1
6. Hull Identification Number (HIN)i	A. Bow and Stern Cleats2.1
7. Manufacturer's Certification	B. Supporting the Boat2.1
8. Service, Parts and Repair for Your Boat	v 2. Passenger Locations2.2
About Your Limited Warranty	,i 3. Propulsion System2.2
,	4. Basic Boat Dimensions and Clearances2.5
	5. Deck Layout2.6
	6. Helm, Gauge & Switch Layout2.7
Section 1 • Safety	7. Function and Location of Through-Hull Cutouts 2.9
1. Safety Labels1.	8. Description of Major Controls2.10
Legally Mandated Minimum Required Equipment.1.	A. Gear Shift and Throthe Control2.10
3. Fire Extinguishing System1.	D. IIIII 1abs2.11
4. Carbon Monoxide1.	C. Fower Hill Officatio Gauge2.12
5. Lifesaving Equipment1.	D. Trailer Switch2.13
Additional Recommended Equipment for Safe	L. Liigille Alaitii Systeiii2.10
Operation1.	9. Important Gauges2.13
7. Impaired Operation	E A. Smartorait "Gauge System2.13
8. Load Capacity1.	5 D. Factionietei2.12
A. United States1.	c. Oil l'essure, water remperature, opeedonneter
B. International	and ruel Gauges2.12
9. Power Capacity1.	b. Magnetic Compass2.12
10. Propellers1.	
11. Stability1.	
12. Maintain Control	
13. Weather	
14. Chart Your Course	DECITOR CONTO I CON DOM
15. Water Sports1.	1 Dro Loupob Loupob and Doot Loupob Chapklist 2 1
A. Swimming1.	
B. Skiing1.	O Boarding
C. Diving1.1	4 Personal Flotation Devices (PEDs)
16. Emergency Situations1.1	E December Instruction and Location
A. Medical Emergency1.1	6 Starting the Engine
B. Water Rescue1.1	7 Chiffing to Drive the Boot
C. Fire1.1	9 Stopping the Engine
D. Flooding, Swamping and Capsizing1.1	O Chaning Overland
E. Collisions and Leaking1.1	10 Windless (Ontional)
F. Grounding1.1	A To Operate From the Holms
G. Propulsion, Control or Steering Failure 1.1	P. To Operate From the Pour
	C. To Operate Manually:
17. Safety Hot Lines	D. Maintananaa
18. International Requirements	5
A. Fuel and Oil Spillage1.1	
B. Waste Disposal 1.1 C. Excessive Noise 1.1	
D. Wake / Wash 1.1	
20. Nautical Terms	
_u, maanua Tulliu,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	T

21. Key to Symbols on Controls and Prints 1.16

270 SLX Owner's Manual • Table of Contents

1. Bige	Section 4 • Bilge & Underwater Gear	Section 7 • Options & Accessories	
B. Electric Sunpad/Engine Hatch. 4.1 C. Drain Plug. 4.1 D. Bilge Pump	1. Bilge4.1	1. Layout and Accessory Locations7	.1
C. Drain Plug.	A. Fuel & Oil Spillage4.1	2. Water System7	.1
D. Bilge Pump	B. Electric Sunpad/Engine Hatch4.1	A. Sanitizing the Water System7	.1
E. Bilge Blower	C. Drain Plug4.1	B. Water Pump and Filter7	.2
2. Engine and Stern Drive	D. Bilge Pump4.2	C. Winterizing the Water System7	.2
A. Maintenance and Service			
B. Vibration & Causes	2. Engine and Stern Drive4.4	E. Fresh Water Washdown7	.3
C. Impact to Stern Drive	A. Maintenance and Service4.4	3. Gray Water System (Option)7	۷.
D. Propeller Selection	B. Vibration & Causes4.4		
E. Propeller Removal and Installation	C. Impact to Stern Drive4.4		
3. Underwater Gear			
4. Bilge Layout	E. Propeller Removal and Installation4.5		
Section 5 • Fuel System			
6. Steering Wheel Remote Controls 7.7 7. Water Sport Tower (Optional) 7.5 7. Water Sport Tower (Optional) 7. Water Sport Power (Optional) 7.	4. Bilge Layout		
7. Water Sport Tower (Optional) 7.5			
8. Fire Extinguisher Port 7.8 1. Fuel System 5.1 2. Fueling Precautions 5.2 A. Static Electricity and the Fuel System 5.2 B. General: 5.2 C. Before and During Fueling Checklist: 5.3 D. After Fueling Checklist: 5.3 D. C Safety Pin 7.1 D. Refrigerator (Optional) 7.1 D. C Safety Pin 7.1			
1. Fuel System			
2. Fueling Precautions	SECTION 5 • FUEL SYSTEM	8. Fire Extinguisher Port7	3.
2. Fueling Precautions	1. Fuel System5.1		
A. Static Electricity and the Fuel System		A. Extinguisher Indicator Light7	9.
B. General:		B. Manual Fire Extinguishing System Pull	
C. Before and During Fueling Checklist: 5.3 D. After Fueling Checklist: 5.3 D. A Illoany Service And Maintenance 7.11 D. Refrigerator (Optional) 7.11 A. Installation Tips 7.11 B. Canvas Care and Maintenance 7.11 Canvas 9. D. A. Illoany Service And Maintenance 7.11 Canvas 9. Section 8 • Required Inspection, Service & Maintenance 8.1 Section 8 • Required Inspection, Service & Maintenance 8.1 Section 8 • Required Inspection, Service and Maintenance 8.1 Section 8 • Required Inspection, Service and Maintenance 8.1 Section 8 • Required Inspection, Service and Maintenance 8.1 Section 8 • Required Inspection, Service & Maintenance 8.1 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service and Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service and Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service & Maintenance 9.2 Section 8 • Required Inspection, Service &		Handle7	٤.
D. After Fueling Checklist: 5.3 D. After Fueling Checklist: 5.3 10. Refrigerator (Optional) 7.10 11. Canvas 7.11 A. Installation Tips 7.11 B. Canvas Care and Maintenance 7.11 12. Horn 7.11 13. Spot Light (Optional) 7.11 14. Docking Lights (Optional) 7.11 15. Section 8 • Required Inspection, Service & Maintenance 8.1 16. AC System 6.2 17. Installation Tips 7.11 17. Installation Tips 7.11 18. Canvas Care and Maintenance 7.11 19. Horn 7.11 10. Refrigerator (Optional) 7.11 11. Canvas 7.11 12. Horn 7.11 13. Spot Light (Optional) 7.11 14. Docking Lights (Optional) 7.11 15. Section 8 • Required Inspection, Service & Maintenance 9.1 16. AC System 8.1 17. Installation Tips 7.11 18. Canvas Care and Maintenance 7.11 19. Horn 7.11 10. Refrigerator (Optional) 7.11 11. Canvas 7.11 12. Horn 7.11 13. Spot Light (Optional) 7.11 14. Docking Lights (Optional) 7.11 15. Section 8 • Required Inspection, Service & Maintenance 9.1 16. Refrigerator (Optional) 7.11 17. Canvas 7.11 18. Installation Tips 7.11 19. Horn 7.11 11. Docking Lights (Optional) 7.11 12. Horn 7.11 13. Spot Light (Optional) 7.11 14. Docking Lights (Optional) 7.11 15. Horn 9.1 16. Rever and Maintenance 9.1 16. Docking Lights (Optional) 7.11 17. Docking Lights (Optional) 7.11 18. Docking Lights (Optional) 7.11 19. Horn 9.1 19. Horn 9.1 19. Horn 9.1 10. Refrigerator (Optional) 9.1 10. Refrigerator (Optional) 9.1 10. A Installation Tips 8.1 10. Refrigerator (Optional) 9.1 10. Leon 9.1 10. Docking Lights (Optional) 9.1 11. Docking Lights (Optional) 9.1 12. Horn 9.1 13. Spot Light (Optional) 9.1 13. Spot Light (Optional) 9.1 14. Docking Lights (Optional) 9.1 14. Docking Lights (Optional) 9.1 15. Leon 9.1 16. AC System 9.1 18. A Eleon 9.1 19. Horn 9.1 19. Docking Lights (Optional) 9.1 19. Docking Lights		C. Safety Pin7.1	(
11. Canvas		10. Refrigerator (Optional)7.1	(
B. Canvas Care and Maintenance		11. Canvas7.1	(
B. Canvas Care and Maintenance		A. Installation Tips7.1	11
1. DC System 6.1 A. Direct Current (DC) 6.1 B. Recommended Batteries 6.2 C. Battery Switch 6.2 lignition Protection 6.2 3. Fuses 6.3 4. 12 Volt Accessory Receptacle 6.4 5. Lighting 6.4 6. AC System 6.6 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.12 13. Spot Light (Optional) 7.11 14. Docking Lights (Optional) 7.11 14. Docking Lig			
A. Direct Current (DC)	Section 6 • Electrical System	12. Horn7.1	11
A. Direct Current (DC) 6.1 B. Recommended Batteries 6.2 C. Battery Switch 6.2 2. Ignition Protection 6.2 3. Fuses 6.3 4. 12 Volt Accessory Receptacle 6.4 5. Lighting 6.4 6. AC System 6.6 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.2	1 DC System 6.1	13. Spot Light (Optional) 7.1	11
B. Recommended Batteries 6.2 C. Battery Switch 6.2 2. Ignition Protection 6.2 3. Fuses 6.3 4. 12 Volt Accessory Receptacle 6.4 5. Lighting 6.4 6. AC System 6.6 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.12 SECTION 8 • REQUIRED INSPECTION, SERVICE & MAINTENANCE 1. Summary Guide for Inspection, Service and Maintenance 8.1 2. Useful Service Information 8.2 3. Inspection, Service and Maintenance Protocol 8.4 4. Winterization Checklist for Boats Stored on Land 8.5 4. Winterization Checklist for Boats Stored on Land 8.5 5. E. Water System 8.6 6.2 SECTION 8 • REQUIRED INSPECTION, SERVICE & MAINTENANCE 1. Summary Guide for Inspection, Service and Maintenance Protocol 8.1 6.4 6.4 6.4 6.4 6.4 6.5 Lighting 10.5 6.4 6.4 6.4 6.4 6.4 6.4 6.4 6.5 Lighting 10.5 6.4 6.4 6.4 6.4 6.4 6.4 6.4 6.4 6.4 6.4	· · · · · · · · · · · · · · · · · · ·	14. Docking Lights (Optional) 7.1	11
C. Battery Switch			
2. Ignition Protection 6.2 3. Fuses 6.3 4. 12 Volt Accessory Receptacle 6.4 5. Lighting 6.4 6. AC System 6.6 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.2 SECTION 8 • REQUIRED INSPECTION, Service & MAINTENANCE 1. Summary Guide for Inspection, Service and Maintenance 8.1 2. Useful Service Information 8.2 3. Inspection, Service and Maintenance Protocol 8.4 4. Winterization Checklist for Boats Stored on Land 8.5 4. Winterization Checklist for Boats Stored on Land 8.5 5. Engines 8.5 6.8 6.9 6.9 6.9 6.9 6.9 6.9 6.9 6.9 6.9 6.9			
3. Fuses			
4. 12 Volt Accessory Receptacle 6.4 5. Lighting 6.4 6. AC System 6.6 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.2 4. Vinterization Checklist for Boats Stored on Land 8.5 A. Boat Storage 8.5 B. Engines 8.5 C. Battery(ies) 8.5 C. Battery(ies) 8.5 C. Water System 8.6 C. Wa			
5. Lighting		Maintenance	
6. AC System 6.6 Maintenance 8.1 7. Main Distribution Panel Controls & Functions 6.6 8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power 6.8 C. Maintenance for Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.12	· · · · · · · · · · · · · · · · · · ·	Summary Guide for Inspection, Service and	
7. Main Distribution Panel Controls & Functions	- 9 9		1
8. Shore Power (Optional) 6.7 A. To Connect and Turn on Shore Power 6.7 B. To Disconnect Shore Power 6.8 C. Maintenance for Shore Power Cable & Shore Power Inlet 6.9 9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.12	•		
A. To Connect and Turn on Shore Power			
B. To Disconnect Shore Power	· · · · · · · · · · · · · · · · · · ·	·	
C. Maintenance for Shore Power Cable & Shore Power Inlet			
Power Inlet			
9. Servicing the Main Distribution Panel 6.9 10. Battery Charger / Converter 6.9 11. Ground Fault Interrupter Receptacle (GFI) 6.10 12. Electrolytic Corrosion and Zinc Anodes 6.11 13. Marine Electronic Cathodic Anti-Corrosion System 6.12 B. Engines 8.5 C. Battery(ies) 8.5 D. Head System 8.6 E. Water System 8.6			
10. Battery Charger / Converter6.9C. Battery(ies)8.511. Ground Fault Interrupter Receptacle (GFI)6.10D. Head System8.612. Electrolytic Corrosion and Zinc Anodes6.11E. Water System8.613. Marine Electronic Cathodic Anti-Corrosion SystemF. Fuel Systems8.6			
11. Ground Fault Interrupter Receptacle (GFI)6.10D. Head System8.612. Electrolytic Corrosion and Zinc Anodes6.11E. Water System8.613. Marine Electronic Cathodic Anti-CorrosionF. Fuel Systems8.6System6.12			
12. Electrolytic Corrosion and Zinc Anodes			
13. Marine Electronic Cathodic Anti-Corrosion F. Fuel Systems			
System6.12		· ·	
		1 . 1 dei Gysteins 0.	٠. ر

viii

270 SLX Owner's Manual • Table of Contents

5. Fitting out After Storage	8.7
A. Fuel System	
B. Battery (ies)	8.7
C. Miscellaneous	8.7
6. Security Considerations	8.7
7. Seacock Lubrication	8.8
8. Quick Reference Checklist	8.9
A. Boarding the Boat*	
B. Preparing to Depart and after Launching .	
C. While Underway	8.11
D. Returning to Port	8.11
E. Securing the Boat	8.12
F. If the Engine Does Not Start	8.12
G. Operating the Generator	8.13
9. After Market Equipment Checklist	
10. Maintenance Log	
Section 9 • Care & Refinishing	
1. Paint Cleaning Agents & Other Substances	9 1
Fiberglass & Gelcoat	
3. Stains & Scratches	
4. Permanently Moored or Docked Boats	
5. Care for Bottom Paint	
6. Topside Areas	
A. Stainless Steel and Alloy Fittings	
B. Salt Crystals	
7. Gauge & Switch Panels	
8. Acrylic Plastic Sheeting (Plastic Glass)	
9. Canvas and Clear Vinyl	
10. Exterior Upholstery Fabric	
11. Interior Upholstery Fabric	

INDEX

Information in this publication is based upon the latest product specifications available at printing. Sea Ray® Boats, Inc. reserves the right to make changes at any time, without notice, in the colors, equipment, specifications, materials and prices of all models, or to discontinue models. Should changes in production models be made, Sea Ray® is not obligated to make similar changes or modifications to models sold prior to the date of such changes.

Owner's Manual
270 Select EX
Printed in the U.S.A. January 2005, Revised July 2005
© Sea Ray Boats, Inc. • A Brunswick Company
MRP #1803645

Sea Ray Boats, Inc. 2600 Sea Ray Blvd., Knoxville, TN 37914 For information call 1-800-SRBOATS or fax 1-314-213-7878 (International 1-314-216-3333)

Internet Address: http://www.searay.com

Note: Not all accessories shown in pictures or described herein are standard equipment or even available as options.

Options and features are subject to change without notice.

The following are registered trademarks of the Brunswick Corporation: Sea Ray® & The SR Wave Logo



SAFE BOATING MEANS:

- Knowing the limitations of your boat;
- Following the rules of the road;
- Keeping a sharp lookout for people and objects in the water:
- Not boating in water or weather conditions that are beyond the boat's and the operator's capability;
- Never boating when the operator is under the influence of drugs or alcohol;
- Being aware of your passengers' safety at all times; and
- Reducing speed when there is limited visibility, rough water, nearby people in the water, boats, or structures.

Boating in beautiful weather and calm water conditions can be a wonderful experience. Pleasurable boating, however, requires considerably greater skills than operating a land vehicle. To obtain these skills, you must:

- Take a Coast Guard, U.S. Power Squadron or equivalent boating safety course. Call the Boat/ U.S. Foundation at 1-800-336-2628 for information on available courses.
- Get hands-on training on how to operate your boat properly.

In Addition:

- Maintain your boat and its safety and other systems as recommended in this manual.
- Have the boat inspected by a qualified mechanic or dealer, at least annually.
- Ensure that the Coast Guard required safety equipment is on board and functions. (See page 1.2).

1. SAFETY LABELS

Safety precautions are given throughout this manual and labels are mounted at key locations throughout the boat. This safety information advises the owner/operator and passengers of imperative safety precautions to follow when operating and/or servicing equipment.

- Fig. 1.17.1 and 1.18.1 show the location of the safety labels on your boat.
- Do not remove or obstruct any safety label.
- Replace any label which becomes illegible. Replacement safety labels can be obtained by calling your dealer or Sea Ray at 1-800-SRBOATS (International 1-314-216-3333) for information on how to contact the manufacturing facility for your boat.

The meaning associated with each of the four basic types of label is:

A DANGER

DANGER – Immediate hazards which WILL result in severe personal injury or death if the warning is ignored.

A WARNING

WARNING – Hazards or unsafe practices which COULD result in severe personal injury or death if the warning is ignored.

A CAUTION

CAUTION – Hazards or unsafe practices which could result in minor injury or product or property damage if the warning is ignored.

NOTICE

Information which is important to proper operation or maintenance, but is not hazard-related.

2. LEGALLY MANDATED MINIMUM REQUIRED EQUIPMENT

Consult your national boating law enforcement agency.

The following equipment is the minimum required by the U.S. Coast Guard for a boat 26' to less than 40' [7.9 meters to less than 12 meters] in length.

Personal Flotation Devices (PFD's): One Coast Guard approved Type I, II or III device is mandatory for each person aboard. One throwable Type IV device is also required to be on board. A Type V device is acceptable if worn for approved use. See Page 1.4 for a description of these PFD classifications. Always wear a PFD when boating.

Fire Extinguisher - Portable: If no fixed fire extinguishing system is installed in the engine and generator spaces, the U.S. Coast Guard requires two (2) Type B-1 or one (1) Type B-2 fire extinguisher be on board. If your boat is equipped with a fixed fire extinguishing system in the engine and generator spaces, the U.S. Coast Guard requires one (1) Type B-1 fire extinguisher be on board. The American Boat and Yacht Council (ABYC) recommends that you have three (3) Type B-1 ABC fire extinguishers on board located outside the engine compartment, at the helm station and in the galley.

Whistle, Horn: You must have on board some means of making a loud sound signal, for example, whistle or horn.

Visual Distress Signals: If you operate your boat in coastal waters or on the Great Lakes, you must have visual distress signals for day and night use on board. At least three (3) U.S. Coast Guard approved pyrotechnic devices marked with date showing service life must be carried, be readily accessible, in serviceable condition and not expired. Store pyrotechnic signals in a well-marked waterproof container in a dry location.

Other: Your Sea Ray is equipped with the required navigation lights, engine exhaust and ventilation systems.

3. Fire Extinguishing System

Your boat must be equipped with the fire extinguishing equipment mandated by the U.S. Coast Guard. Your boat is equipped with a fire extinguisher discharge port located under the starboard sunpad cushion (see page 7.8). Your boat may also be equipped with an optional automatic fire extinguisher system (see page 7.9).

IF A FIRE IS SUSPECTED, IMMEDIATELY SHUT DOWN THE ENGINE, POWERED VENTILATION, ELECTRICAL SYSTEMS AND EXTINGUISH ALL SMOKING MATERIALS.

IF THERE IS A FIRE IN THE ENGINE COMPARTMENT DO NOT OPEN THE ENGINE BOX. THIS WOULD FEED OXYGEN TO THE FIRE AND THE FIRE COULD RESTART.

DISCHARGE PORTABLE FIRE EXTINGUISHER THROUGH THE DISCHARGE PORT ON THE SUNPAD/ENGINE HATCH.

Wait at least fifteen (15) minutes before opening the engine compartment. This gives the compartment long enough for hot metals and fuels to cool. Have portable extinguishers at hand and ready to use in case the fire reignites. Do not breathe fumes or vapors caused by the fire.

4. CARBON MONOXIDE

Symptoms of carbon monoxide poisoning are dizziness, ears ringing, headaches, nausea and unconsciousness. A poisoning victim's skin often turns cherry red. Because carbon monoxide gas (CO) is odorless, colorless and tasteless, it is unlikely to be noticed until a person is overcome.

A DANGER

Fumes from engine, generators, and other equipment and appliances using burning fuel contain carbon monoxide.

Carbon Monoxide can kill you.

Open all doors, curtains, windows, and hatches to let fresh air circulate, when running engine, generator or burning any fuel when boat is anchored, moored or docked.

A DANGER

Even in rainy cold weather ventilation must be maintained to avoid Carbon Monoxide poisoning. You will get wet and/or cold.

A DANGER

Sleeping on boat requires an operating Carbon Monoxide detection system in each sleeping location.

Dangerous concentrations of carbon monoxide will be present if:


- the engine and/or generator exhaust systems leak;
- insufficient fresh air is circulating where people are present; and
- fumes move from the rear of the boat into the cockpit and cabin area.

Fig. 1.3.1 gives examples of boat operating conditions that can lead to high concentrations of carbon monoxide gas.

To minimize the danger of CO accumulation when the engine and/or generator are running, or using burning fuel applications:

- Be sure to have sufficient ventilation when using canvas or window-type side curtains when underway, anchored, moored or docked.
- If the convertible top is installed, operate with the forward hatch open and leave cabin door open.
- Operate all burning fuel appliances, such as charcoal, propane, LPG, CNG or alcohol cooking devices in areas where fresh air can circulate. Do not use such devices where there is no noticeable air movement, especially in the cabin, when anchored, moored or docked.
- Do not idle engine without moving boat for more than 15 minutes at a time.
- Inspect the exhaust system regularly. (See Section 8, Required Inspection, Service and Maintenance.

If CO poisoning is suspected, have the victim breath fresh air deeply. If breathing stops, resuscitate. A victim often revives, then relapses because organs are damaged by lack of oxygen. Seek immediate medical attention.



5. LIFESAVING EQUIPMENT

Even strong swimmers can tire quickly in the water and drown due to exhaustion, hypothermia, or both. The buoyancy provided by a personal flotation device (PFD) will allow the person who has fallen overboard to remain afloat with far less effort and heat loss, extending survival time necessary to find and retrieve them.


Boat operators are required to carry one wearable personal flotation device (Type I, II, III or V) for every person on board. Boats must also have at least one throwable device (Type IV).

The law requires that PFD's must be readily accessible, if not worn. "Readily accessible" means removed from storage bags and unbuckled. But, children and nonswimmers must wear PFDs at all times when aboard. It is common sense to have everyone on board wearing PFDs. A throwable device must also be right at hand and ready to toss.


A. PFD CLASSIFICATIONS




Off-Shore Life Jacket (Type I) – most buoyant, it is designed to turn an unconscious person face up; used in all types of waters where rescue may be slow, particularly in cold or rough conditions.



Near-Shore Life Vest (Type II) – "keyhole" vest with flotation-filled head and neck support is also designed to turn a person face up, but the turning action is not as pronounced; used in calm, inland waters or where quick rescue is likely.



Flotation Aid (Type III) – vest is designed so conscious wearers can turn face up; often designed for comfort while engaged in sports such as skiing.



Throwable Devices (Type IV) – horseshoe buoys, ring buoys and buoyant cushions are designed to be grasped, not worn.



Special-Use Devices (Type V) – sailboat harnesses, white-water vests, float coats, and hybrid vests which have minimum inherent buoyancy and an inflatable chamber.

Before purchasing PFDs, ensure that there is an attached tag indicating they are approved by the U.S. Coast Guard or by your national boating law enforcement agency.

Children and nonswimmers must wear PFDs at all times when aboard. All passengers and crew should wear them. A loose PFD is often useless in an emergency.

The operator is responsible for instructing everyone aboard on the location and use of PFDs.

Size PFDs for the wearer. Children require special attention in the use of PFDs.

Test PFD buoyancy at least once a year.

6. Additional Recommended Equipment for Safe Operation

In addition to legally mandated equipment, the following items are necessary for safe boating, especially if your boat is out of sight of land.

- First aid kit
- Visual distress signals for day and night use (required in some areas; consult local regulations)
- Charts of your intended cruising area
- Compass
- GPS or Loran position locating devices



- Marine VHF radio with weather channels
- Emergency position-indicating radio beacon (EPIRB)
- Manual bilge pump
- Moisture repellant
- Anchors, chain and line (The anchors must be properly sized for your boat. Ask your dealer or marine supply store for recommendations).
- Mooring lines
- Fenders
- Boat hook
- Waterproof flashlight(s)
- Extra batteries for flashlights and portable electronic devices
- High power spotlight, if you intend to boat at night
- Spare keys
- Instruction manuals for engine and accessories
- Lubricating oil
- Tool kit:
 - Assorted screwdrivers (Phillips and flat blade)
 - Pliers (regular, vise-grip, and tongue & groove)
 - Wrenches (box, open-end, allen, adjustable)
 - Socket set (metric or U.S. Standard as appropriate)
 - Electrical tape and duct tape
 - Hammer
 - Utility Knife
- Spare parts kit (spark plugs, fuses, hose clamps and ask your dealer to recommend other parts)
- Extra propeller

7. IMPAIRED OPERATION

Drugs and/or alcohol will prevent you from operating your boat safely. This single factor is involved in more marine accidents and deaths than any other. The detrimental effects of alcohol and drugs are increased by the wind, waves and sun, quickly impairing your ability to react properly and promptly in an emergency.

A WARNING

Drugs and/or alcohol impair the operator's ability to control the boat safely.

Death or serious injury can result from improper boat operation.

8. LOAD CAPACITY

A. UNITED STATES

Use common sense and sound judgement when placing equipment and/or passengers in your boat. The number of people on board must be reduced if you go out in poor weather and rough water.

- The number of seats does not indicate how many people a boat can carry in poor weather and rough water.
- Above idle speed, all passengers must be seated on the seats provided.

The United States Coast Guard does not provide specific numbers for passenger capacity or cargo weight for recreational vessels 26 feet (7.92 meters) or larger. For safety sake, use the following information provided for the international loading standards for maximum number of passengers plus cargo weight.


B. International

The certification plate (See Fig. 1.6.1) located near the helm indicates maximum weight and number of persons your boat can handle under calm sea conditions. **Do not exceed the load capacities stated.** The number of people on board must be

reduced if you go out in poor weather and rough water.

The information present on the certification plate does not relieve the operator from responsibility. Use common sense and sound judgement when placing equipment and/or passengers in your boat.

- Do not load to capacity in poor weather or rough water.
- The number of seats does not indicate how many people a boat can carry in poor weather and rough water.
- Above idle speed, all passengers must be seated on the seats provided.



A WARNING

When engine is running, keep passengers away from areas not designed for riding, such as seat backs, bow, gunwales, transom platform, swim platform, front and rear decks and on sun pads.

Passengers can fall overboard if not seated properly on the seats provided.

A DANGER

Never carry more weight or passengers than indicated on the certification plate, regardless of weather or water conditions.

The boat can capsize, swamp or sink.

9. Power Capacity

Your boat's engine and accessories were selected to provide optimum performance and service. Installing a different engine or other accessories may cause unwanted handling characteristics. Should you choose to install a different engine or to add accessories that will affect the boat's running trim, have an experienced marine technician perform a safety inspection and handling test **before** operating your boat again. Certain modifications to your boat will result in cancellation of your warranty protection. Always check with your dealer **before** making any modifications to your boat.

10. Propellers

Your Sea Ray® has been equipped with a propeller which our tests have shown to be the best suited for general use with our engine under normal conditions and load. Do not change the pitch of your propeller without getting your dealer's recommendations first. If you change to a different propeller pitch, under no circumstances use a propeller which allows the engine to operate at higher than recommended RPM. (Your engine manual specifies the maximum recommended RPM).

To maintain rated power, propellers should be free of nicks, excessive pitting and any distortions that alter them from their original design. Badly damaged propellers should be replaced, but those that are chipped, bent or merely out of shape can be reconditioned by your marine dealer.

It is advisable to carry an extra propeller aboard in case you damage the one in use.

11. STABILITY

Your boat was manufactured to specific stability and flotation standards for the capacity shown on the certification plate. Any increase from the recommended load capacities will put your boat in jeopardy of capsizing, swamping and/or sinking.

IN ADDITION:

- Stability may be substantially reduced if equipment is added above the deck.
- Stability is substantially reduced by loose fluids or weight within the hull. Keep bilge area as dry as possible, and close all openings, hatches and windows in rough weather.

A WARNING

Distribute passengers and gear as uniformly as possible from front to rear and left to right.

The manufacturer's load rating is the maximum allowed under calm conditions.

Reduce boat loading if weather, water or other conditions are adverse.

12. Maintain Control.

On the water there are no marked traffic lanes, no traffic signs or lights, and boats have no turn signals. The boat operator must keep his or her attention focused not only on what's ahead but what's on the left, right and behind the boat.

The operator must always be alert to approaching boats (from the rear, right and left sides, as well as those ahead). There can be people in the water, partially submerged debris, and other navigational hazards such as rocks, sand bars, dangerous currents, to name a few.

Your passengers are relying on you to operate and maneuver the boat safely so that they are not in danger of going overboard. If you turn to quickly, increase or decrease speed abruptly, your passengers are at risk of being thrown overboard or thrown about the boat.

When visibility becomes impaired because of weather, time of day or high bow angle you must slow down so that you have sufficient time to react if an emergency occurs. Nearby boats face similar risks in avoiding a collision with you.

A. GENERAL CONSIDERATIONS

- Know how your boat handles under different conditions. Recognize your limitations and the boat's limitations. Modify speed in keeping with weather, sea and traffic conditions.
- Instruct passengers on location and use of safety equipment and procedures.
- Instruct passengers on the fundamentals of operating your boat in case you are unable to do so.
- You are responsible for passenger's actions. If they place themselves or the boat in danger, immediately correct them.

A WARNING

Death or serious injury can result if you fail to observe these safety rules:

- Anyone who controls the boat must have taken a boating safety course and have trained in the proper operation of the boat.
- Always operate the boat at speeds that will not put people or property in danger.
- Be constantly aware of conditions in all directions when underway and before turning.
- Reduce speed, use a lookout to identify possible hazards or difficulties, and turn on navigation lights when:
 - visibility is impaired;
 - in rough water; or
 - in congested waterways.
- Watch your wake. It can capsize a small boat or damage moored boats or other property. You are responsible for damage caused by your wake.

13. WEATHER

There are four design categories of boats based upon their ability to withstand wind and sea or water conditions:

A. Ocean

Wind speed: above 40 knots (46 mph) Wave height: above 4 meters (13 feet) Boat may be used for extended ocean voyages.

B. Offshore

Maximum wind speed: 40 knots (46 mph) Maximum wave height: 4 meters (13 feet) Boat can be used offshore, but not for extended ocean voyages.

C. Inshore

Maximum wind speed: 27 knots (31 mph) Maximum wave height: 2 meters (6.5 feet) Boat use is limited to coastal waters, large bays, estuaries, lakes and rivers.

D. Sheltered waters

Maximum wind speed: 15 knots (18 mph) Maximum wave height: 0.5 meters (1.5 feet) Boat use is limited to small lakes, rivers and canals.

A DANGER

DO NOT ATTEMPT TO BOAT IN SEVERE WEATHER CONDITIONS

DEATH OR SERIOUS INJURY CAN OCCUR

GET TO SHORE BEFORE
THE WEATHER TURNS BAD

Your 270 Select EX is Design Category C.

The wind speed and wave height specified as the upper limit for your category of boat does **not** mean that you or your passengers can survive if your boat is exposed to these conditions. It is only the most experienced operators and crew that may be able to operate a boat safely under these conditions. You must always be aware of weather conditions and head for port or protected waters in sufficient time to avoid being caught in high winds and rough water. **Do not take chances!**

Getting caught in severe weather is hazardous. Bad weather and/or rough sea or water conditions can cause an unsafe situation. Consult local weather information, or listen to the NOAA weather reports for the latest weather conditions or any impending deterioration of the weather before setting out and while underway. Following are a few basic weather-related rules:

- Check the weather forecast and the water conditions before leaving and while underway.
- A sudden change in wind direction or speed or an increase in wave height indicates deteriorating weather.
- Have everyone wear a personal flotation device.
- If a storm approaches, immediately seek a safe harbor.
- If a storm hits, have everyone sit in the cabin or on the cockpit deck in the boat. Head the bow into the wind with enough power to maintain slow headway.
- If you encounter fog, determine your position, set a safe course, slow down and alert other boats of your presence with a sound signal.
- If a lightning storm approaches, the safest action is to dock and disembark. If you cannot return to shore, have passengers go **inside** the cabin and remain there until the storm passes.
- Lightning seeks a ground when it strikes. The
 best protection is a properly grounded lightning
 rod placed high enough over the deck to provide
 a protective umbrella over the hull. Depending
 upon the likelihood of your being in a lightning
 storm, consult your dealer for installation of a
 lightning rod. Stay clear of the lightning rod, all
 attached wiring and all metal parts of the boat.
- Stay out of the water during a lightning storm. If caught swimming during a storm, get back into the boat and remain there until the storm passes.

14. CHART YOUR COURSE

A WARNING

Hitting an object in or under the water or boating in dangerous currents can cause serious injury or death to boat occupants.

You must know where the hazards are and avoid them.

In uncharted waters, boat very slowly and post a lookout.

To avoid boating in unsafe areas where there are underwater obstructions, shallow water, unnavigable conditions such as dangerous currents, and others, you must chart a course. This means having and using the National Oceanic and Atmospheric Administration (NOAA) charts for coastal waters, observing and understanding all navigational aids, using the knowledge and guidance of experienced boaters, and being aware of the tide times where appropriate.

WARNING

Shut engine off if an object is struck or if you run aground.

Check for hull leaks and drive line damage, before restarting engines.

Use hand pump if bilge pumps don't remove water.

Boat very slowly, if you must proceed with a damaged drive line.

If you are in an unfamiliar area without knowledge of the hazards, proceed very slowly and have someone watch for hazards.

Let others know where you are going. A float plan describes your intended cruising course and itinerary, boat description, and your expected time and date of return. Give the float plan to a friend or relative, so they can give the information to a national boat agency, like the U.S. Coast Guard, in the event you fail to return.

15. WATER SPORTS

A WARNING

Your boat can kill or injure persons in the water.

Always stay away from areas designated for swimming or diving. Unless you are towing a skier, stay away from water ski areas. Recognize markers used for such areas.

When engine is running, close and lock transom door and do not permit anyone to use boarding ladder and swim platform.

A. SWIMMING

- Do not permit anyone to swim from a moving boat, or a boat with an engine running.
- Many localities prohibit swimming from boats except in designated areas.
- Make sure boat's engines are turned off before allowing people to swim anywhere near your boat. Shut the engine OFF and remove the key from the ignition switch so that no one can accidentally start the engine while swimmers are nearby.
- Turn off engines when taking swimmers or skiers aboard or when they are entering the water. Never permit use of the transom or swim platform while engines are running.
- Slow down and look for swimmers or skiers when cruising in an area where there might be persons in the water.

B. SKIING

A WARNING

Skiers must wear an approved PFD.

It is advised that you become familiar with water skiing safety and hand signals as you will most likely, on occasion, find yourself in the vicinity of or engaging in water skiing activity.

Anyone who water skis must know how to swim.

- Never drive the boat directly behind a water skier. At 22 knots (25 m.p.h.), it takes only 5 seconds to overtake a fallen skier who was 60 meters (200 feet) in front.
- Keep a downed skier in sight and on the operator's side of the boat when approaching the skier. Never back up to anyone in the water.
- Learn the signals to communicate with a skier.
 The skier is to control the boat through hand signals (Fig. 1.10.1).

Turn – Arm raised, circle with index finger extended.

Skier in Water – Extend one ski vertically out of water.

Back to Dock – Pat top of head.

Cut Motor – Draw finger across throat.


Slow Down – Thumb pointed down or palm down, move hand up and down.

Faster – Thumb pointed up or palm up, move hand up and down.

OK – Raise arm and form a circle with thumb and index finger.

Stop – Raise arm with palm vertical and facing forward.

Turn Right – Extend arm out from body to the right.



Turn Left – Extend arm out from body to the left.

OK After a Fall – Clasp hands together overhead.


 If the skier suddenly releases the tow rope, it can backlash into cockpit. Spotters who are watching the skier must be aware of this fact and be prepared to deflect the rope by hand to avoid injury.

C. DIVING

Recognize and respect diving flags (Fig. 1.10.2). Keep at least 30 meters (100 feet) away.

Sport Divers Flag – Red flag with diagonal white stripe marks a diver in the water.

<u>Code Alpha Flag</u> – Blue and white pennant designates boat being used in dive operations.



In General

When engaged in water sports, be safe and courteous to others sharing the water:

- Be considerate to fishermen.
- Do not water ski in congested areas.
- Keep the boat and skier away from navigation markers.
- Stay well clear of other boats and skiers.

16. Emergency Situations

Prevention is the safest approach. We hope that you are never involved in an emergency situation.

ASSISTING OTHER BOATERS

All boaters have a legal obligation to help other boaters who are in distress, as long as rendering assistance does not endanger you, your passengers or your boat.

If you are involved in an emergency situation, it is imperative that you know how to react, in order to protect the lives in your care.

A. MEDICAL EMERGENCY

You may be far from professional medical help when you are boating. At least two people on board your boat should be CPR certified, and should have taken a first aid course. Equip your boat with a first aid kit.

B. WATER RESCUE

A person who has fallen overboard will die from hypothermia in water temperatures below 70°F if not rescued quickly. Water rescue consists of three steps: returning to the victim, making contact with the victim, and getting the victim back on board.

RETURNING TO THE VICTIM

- Immediately make everyone aware of the incident and keep the victim in sight.
- Slow the boat and keep pointing toward the person overboard. At night, direct the best available light source at the person.
- Throw a life preserver, even if the person is wearing a PFD. It will serve as another marker.

MAKING CONTACT

- Stop or slow the boat and circle toward the victim.
- Try to approach heading into the wind or into the waves.

- Keep the victim constantly in sight.
- When almost alongside, stop the engine in gear to prevent propeller "windmilling."

GETTING BACK ABOARD

- Try to reach the victim with a pole, or by throwing a life preserver. Do not swim to rescue the victim, except as a last resort.
- Assist the person in boarding the boat. The person should normally be brought in over the stern.
- If the person is injured or cannot get into the boat, a rescuer should put on a PFD with a safety line attached to the boat and enter the water to assist the victim.
- Handle the victim with care. Spinal injuries may have occurred.

C. FIRE

Fire is a serious boating hazard. Boats will burn quickly. Do not remain on board and fight a fire for more than a few minutes. If the fire cannot be extinguished within a few minutes, abandon the boat.

Have fire extinguishers handy. A small fire can be extinguished quickly with the right size and type of fire extinguisher.

- Extinguish smoking materials, shut off blowers, stoves, engines and generators.
- Throw burning materials overboard, if possible.
- If the fire is accessible, empty the contents of fire extinguishers at the base of the fire.
- If the fire is in the engine compartment and you have an automatic extinguisher for the engine, wait 15 minutes before opening the compartment. Have a portable extinguisher ready in case the fire flares up.
- Signal for help.
- Grab distress signals and survival gear. Put on PFDs. Prepare to abandon ship.

D. FLOODING, SWAMPING AND CAPSIZING

In the event of flooding, swamping or capsizing:

- Try to shut off engines, generators and blowers, before leaving the boat.
- Have everyone put on Personal Flotation Devices (PFDs).
- Account for all who were on board.
- If the boat is floating stay with the boat. Hang on, or climb on the boat and signal for help.
- Only as a last resort should you attempt to swim to shore - it is further away than it looks and you can tire and drown.

E. COLLISIONS AND LEAKING

In the event of collision and leaking:

- Slow down or stop to reduce water intake, unless maintaining speed will keep the hole above water.
- Switch on bilge pumps.
- If equipped, operate the manual bilge pump if the powered bilge pumps can't handle the water flow.
- Account for everyone on board and check for injuries.
- Have everyone put on PFDs.
- Stay with the boat.
- Signal for help.
- If a leak patch is attempted, it should be done from the outside.
- In the event of a collision, you are required to file an accident report. Contact a state enforcement agency or the nearest Coast Guard office. If you are boating outside of U.S. waters, consult the nation you are visiting for accident reporting requirements.

F. GROUNDING

In the event of running aground:

- Check for leaks. If water is coming in, stop the intake of water before attempting to get the boat free.
- Inspect for damage to the hull, propulsion and steering systems.
- Determine if the tide, wind and current will drive the boat harder aground or will help to free it.
- Determine the water depth all around the boat, and the type of bottom (sand, mud, rocks, etc.).
 If it can be done without exposing persons to risk of injury, the boat should be moved away from hard obstructions and toward open water with soft ground.
- Do not attempt to have your boat towed by other than a trained and competent service, such as the Coast Guard or a salvage company. Recreational craft are not designed to tow other recreational craft.

G. Propulsion, Control or Steering Failure

If the drive train fails, or controls or steering do not respond properly at all:

- Shut off engine.
- Put out the anchor to prevent drifting.
- Determine whether or not you can repair the problem yourself. See the proper manuals for assistance in troubleshooting the engine, steering and engine controls.
- If you are not sure you can fix the problem, or if conditions are adverse, signal for help.

17. SAFETY HOT LINES

The safety information in the preceding pages gives only the general areas of concern for boating safety. It is not intended to be, nor can it be, exhaustive. You must take a boating safety course, and get hands-on instruction in the proper and safe operation of your boat from experienced persons before cruising.

The U.S. Coast Guard offers many pamphlets on safety and other information not covered in this book. Contact your local Coast Guard unit or call the toll-free safety hot lines below for information.

- U.S. Coast Guard 1-800-368-5647
- Canadian Coast Guard 1-800-267-6687

In other countries, ask your marine dealer for information on how to contact the national boating law enforcement agency.

18. International Requirements

This vessel and its systems have been constructed in accordance with standards and specifications in effect at the time of manufacture as published by the various regulatory authorities listed below.

- 1. Ministere De La Mer France
- 2. Registro Italiano Navale Italy
- 3. Det Norske Veritas Norway
- 4. Securite des Nauires Canada
- 5. J.C.I. (Japan Craft Inspection) Japan
- 6. N.K.K. (Nippon Kaiji Kyokai) Japan
- 7. B.S.I. (British Standards Institute) England
- 8. Ministerio Obras Publicas Y Transportes Spain
- 9. EC Recreational Craft Directive European Community.

Further information concerning these requirements may be obtained from Sea Ray[®] Customer Service: 1-800-SRBOATS.

19. Environmental Considerations

The following warning is offered for boats sold in the State of California in accordance with California Health & Safety Code §§ 25249.5-.13:

A WARNING

A wide variety of components used on this vessel contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm.

EXAMPLES INCLUDE:

- Engine and generator exhaust
- Engine and generator fuel, and other liquids such as coolants and oil, especially used motor oil
- Cooking fuels
- Cleaners, paints, and substances used for vessel repair
- Waste materials that result from wear of vessel components
- Lead from battery terminals and from other sources such as ballast or fishing sinkers

TO AVOID HARM:

• Keep away from engine, generator, and cooking fuel exhaust fumes.

A. FUEL AND OIL SPILLAGE

Regulations prohibit discharging fuel or oily waste in navigable waters. Discharge is defined as any action which causes a film, sheen or discoloration on the water surface, or causes a sludge or emulsion beneath the water surface. A common violation is bilge discharge. Use rags or sponges to soak up fuel or oily waste, then dispose of it properly ashore. If there is much fuel or oil in the bilge, contact a knowledgeable marine service to remove it. Never pump contaminated bilge overboard. Help protect your waters.

Fill tank(s) less than rated capacity. Allow for fuel expansion.

B. WASTE DISPOSAL

- Many areas prohibit overboard sewer discharge. Close and disable flow-through waste systems to prevent discharge in such areas.
- Bag all refuse until it can be disposed of ashore.
 Regulations prohibit disposal of plastic anywhere in the marine environment and restrict other garbage disposal within specified distances from shore.

NOTICE

- There is a possibility of being fined for having an operable direct overboard discharge of waste in some waters. Removing seacock handle, in closed position, or other means must be used to avoid fine.
- It is illegal for any vessel to dump plastic trash anywhere in the ocean or navigable waters of the United States.

A CAUTION

FOR BOATS WITH VACUFLUSH® HEADS ONLY

Do not place facial tissues, paper towels or sanitary napkins in head. Such material can damage the waste disposal system and the environment.

C. Excessive Noise

Many areas regulate noise limits. Even if there are no laws, courtesy demands that boats operate quietly.

D. WAKE / WASH

WARNING

SPEED HAZARD - Watch your wake. It might capsize a small craft. You are responsible for damage caused by your wake.

Power boat wakes can endanger people and vessels. Each power boat operator is responsible for injury or damage caused by the boat's wake. Be especially careful in confined areas such as channels or marinas. Observe "no wake" warnings.

A CAUTION

Reduce speed in congested waterway.

Be alert for No Wake markers.

20. Nautical Terms

Abeam – object 90 degrees to center line on either side of boat.

Abaft – a point on a boat that is aft of another.

Aft – toward the rear or stern of the boat.

Beam – the width of a boat.

Bow – the fore part of a boat.

Bow Eye – bolt with looped head mounted on extreme forward part of bow.

Bulkhead – vertical partition in a boat.

Chine – meeting juncture of side and bottom of boat.

Chock – deck fitting, used as guides for mooring or anchor lines. Also, a wedge to stop wheels from rolling.

Cleat – deck fitting with arms or horns on which lines may be made fast.

Cockpit – an open space from which a boat is operated.

Deck – upper structure which covers the hull between gunwales.

Draft – depth of water required to float boat and its propulsion system.

Fathom – six feet.

Fenders – rope or plastic pieces hung over the side to protect the hull from chafing.

Freeboard – height of exposed hull from water line to deck.

Ground tackle – general term referring to anchors, anchor lines, etc.

Gunwale (pronounced gun'l) – meeting juncture of hull and deck.

Hatch – an opening in deck to provide access below.

Head – toilet or toilet area in a boat.

Headroom – vertical distance between the deck and cabin or canopy top.

Helm – steering console.

Hull – the basic part of a boat that provides buoyancy to float the weight of the craft and its load.

Keel – the major longitudinal member of a hull; the lowest external portion of a boat.

Knot – unit of speed in nautical miles per hour.

Lee – the side that is sheltered from the wind.

PFD – Personal Flotation Device; life preserver.

Port – term designating left side of the boat.

Rudder – movable fixture at the stern used for steering.

Scupper – hole permitting water to drain overboard from deck or cockpit.

Sheer – curve or sweep of the deck as viewed from the side.

Snub – to check or tighten a line suddenly.

Starboard – term designating right side of the boat

Stern - the aft end of a boat.

Stern drive – outboard unit of an inboard/outboard (I/O) engine installation.

Stringer – longitudinal members fastened inside the hull for additional structural strength.

Transom – transverse part of stern.

Wake – disturbed water that a boat leaves behind as a result of forward motion.

Windward – toward the direction from which the wind is blowing.

21. KEY TO SYMBOLS ON CONTROLS AND PRINTS

These symbols may be found on your controls and gauges and/or used in this owner's manual. This page is to help you understand what the symbols mean.
































































































22. WARNING LABEL LOCATIONS



WARNING LABEL LOCATIONS (Fig. 1.18.1)

Save Our Seas

It is *illegal* to dump plastic trash anywhere into the ocean or navigable waters of the United States. Violation of these requirements may result in civil penalty up to \$25,000, a fine of \$50,000 and imprisonment for up to five years.

<u>PLASTIC</u> - Includes but is not limited to: plastic bags, styrofoam cups and lids, six-pack holders, stirrers, straws, milk jugs, egg cartons, synthetic fishing nets, ropes, lines, and bio or photo degradable plastics.

GARBAGE - Means paper, rags, glass, metal, crockery (generated in living spaces aboard the vessel-what we normally call trash), and all kinds of food, maintenance and cargo-associated waste.

"Garbage" does not include fresh fish or fish parts, dishwater, and gray water.

INSIDE 3 MILES

(and in U.S. Lakes, Rivers,
Bays and Sounds)
PLASTICS
DUNNAGE, LINING AND PACKING
MATERIALS THAT FLOAT
ANY GARBAGE EXCEPT DISHWATER/
GRAYWATER/FRESH FISH PARTS

3 TO 12 MILES

PLASTICS
DUNNAGE, LINING AND PACKING
MATERIALS THAT FLOAT
ANY GARBAGE NOT GROUND TO LESS
THAN ONE SQUARE INCH

12 TO 25 MILES

PLASTICS DUNNAGE, LINING AND PACKING MATERIALS THAT FLOAT

12 TO 25 MILES

PLASTICS


LOCATED ON INSIDE OF STARBOARD STORAGE DOOR

<u>DUNNAGE</u>- Material used to block and brace cargo, and is considered a cargo associated waste.

DISHWATER- Means the liquid residue from the manual or automatic washing of dishes and cooking utensils which, have been pre-cleaned to the extent that any food particles adhering to them would not normally interfere with the operation of automatic dishwashers.

GRAYWATER - Means drainage from a dishwasher, shower, laundry, bath, and wash basin, and does not include drainage from toilets, urinals, hospitals, and cargo spaces.

1745



1. 18 270 Select EX

1. Docking/Lifting/Storage

A CAUTION

Do Not use cleats for lifting.

A. BOW AND STERN CLEATS

Cleats must not be used for lifting the boat; they are intended for docking or mooring use only.


When lifting the boat always keep the bow higher than the stern to drain the exhaust lines and to prevent water from running forward through the manifold and into the engine where it can become trapped. It may seem expedient to lift only the stern when changing a propeller, but this can result in water entering the engine cylinders, causing hydrostatic lock and resulting in possible engine failure. Even a small amount of water in the engine can cause rust and is to be avoided.


With fiberglass boats, severe gelcoat crazing or more serious hull damage can occur during launching and hauling if pressure is created on the gunwales by the slings. Flat, wide belting-type slings and spreaders long enough to keep pressure from the gunwales are necessary. Cable-type slings should be avoided. Do not place the slings where they may lift on underwater fittings.

Never hoist the boat with an appreciable amount of water in the bilge. Fuel and water tanks should preferably be empty, especially if of large capacity.

B. SUPPORTING THE BOAT

A cradle is the ideal support for the boat whenever it is not in the water. Properly designed and constructed, it will provide support at the proper points, which is essential to avoid stress on the hull. Do not rest boat on underwater fittings.





2. Passenger Locations

WARNING

Boat motion can be erratic.

You can fall overboard or be injured by hitting something in or on the boat.

All persons must be in cockpit area or cabin and be prepared for sudden boat movement.

Use front or bow deck area only during anchoring, mooring or emergencies.

A WARNING

Wet decks are slippery.

You can be seriously injured if you slip and fall.


Wear slip resistant footwear secured to your feet and hold on to rails or boat structure.

1. When the boat is moving, all passengers must be in the cockpit area or in the cabin and must be on seating provided or, if standing, holding on firmly (Fig. 2.3.1).

While the person at the wheel must alert passengers before any sudden or erratic boat movement, such as crossing wakes, rapid turns, sudden acceleration or deceleration, etc., an emergency action may be necessary before passengers can be warned. All passengers must be prepared for rapid boat movement and be able to hold on to prevent loss of balance.

- 2. When persons are on the working deck area, for anchoring, mooring or in emergencies, they must be holding on and be positioned so as to prevent falling. In bad weather and/or rough water, if it is essential to be on deck, persons should be closely tied to cleats, railing stanchions or other securely fastened boat hardware.
- 3. Engines must be turned off if the boat is near swimmers or persons are on the swim platform or the swim ladder.

Passenger Locations (Fig. 2.3.1)





WARNING

Wet decks are slippery.

You can be seriously injured if you slip and fall.

Wear slip resistant footwear secured to your feet and hold on to rails or boat structure.

A DANGER


Rotating propellers can injure or kill you.

Shut off engine when persons are in water, near boat, on swim platform or ladder.


3. Propulsion System

The engine on your boat is a stern drive propulsion system also known as an inboard-outboard engine. This type of propulsion system has the engine inside the boat secured to the hull's stringers at the rear end of the hull. The stern drive unit, also called the lower unit because it hangs below the hull, is part of the propulsion system that attaches to the outside of the hull or transom. The stern drive unit pivots to steer the boat.

REFER TO THE ENGINE OWNER'S MANUAL FOR OPERATING INSTRUCTIONS AND WARRANTY INFORMATION.



4. Basic Boat Dimensions and Clearances




270 SELECT EX SPECIFICATIONS

(A) Overall Length With Std. Swim Platform 28ft. 6ir	n. 8.69 m
(B) Beam (Width) 9ft.	2.74 m
(C) Draft (Stern Drive Down) 36.5in.	* 92.7 cm*
Draft (Stern Drive Up)20in.*	50.8 cm*
* MINIMUM WATER DEPTH TO PREVENT RUNNING AGROU	UND
Dry Weight 5,555 I	bs. 2,520 kg.
Fuel Capacity 94 gal.	355.8 liters
Usable Fuel 89 gal.	336.9 liters
Water Capacity 21 gal.	79.5 liters
Holding Tank 10 gal.	37.9 liters
Dead Rise 21°	


HEIGHT DIMENSIONS

(D) Keel to Top of Arch 8ft. 11.5ir	n. 2.73 m
(E) Waterline to Top of Arch 7ft. 4in.	2.24 m
(F) Waterline to Top of Windshield 5ft. 3in.	1.6 m
(G) Arch to Top of Mast Light 14in.	35.6 cm


5. DECK LAYOUT




6. Helm, Gauge & Switch Layout




SWITCH PANELS (Fig. 2.7.2)






STARBOARD SWITCH PANEL

HELM LAYOUT (CONTINUED)




7. Function and Location of Through-Hull Cutouts



8. DESCRIPTION OF MAJOR CONTROLS

A. GEAR SHIFT AND THROTTLE CONTROL

The shift/throttle control unit for the engine activates by the shifting mechanism and the throttle. The control must be in the neutral position to start your engine. Moving the lever forward first engages the forward gear. Further forward movement increases engine speed and propeller RPM, moving the boat faster. To shift to reverse, bring the control lever back to the neutral position, then move it further back to engage the reverse gear. Further rearward movement of the lever increases engine speed and propeller RPM, moving the boat faster in reverse.



Shift/throttle controls are equipped with a "throttle only" mechanism which allows the shift mechanism to be disengaged from the throttle. This allows the throttle to be advanced without shifting the transmission when starting. It may be necessary to use the "throttle only" button in order to pump fuel into the engine for ease in starting.

The "throttle only" mechanism may differ from one style gear/throttle unit to another. Refer to your Gear Shift & Throttle Manual for proper operation of this feature.

The throttle control adjusts the RPM of the engine and thus, the rotational speed of the propeller. Regulating the RPM of the engine controls the speed of the boat.

Forward motion creates forward moving water called a "following" wake. If the boat is moving forward and the shift/throttle is moved quickly from forward to reverse, the boat will stop rapidly and then move backward. The following wake continues to move forward and can rise above the transom and flood the boat.

Do not shift into reverse too quickly. Wait for the following wake to dissipate.

A CAUTION

Cockpit can fill with water if boat is moving forward, when it is put into reverse.

Before shifting into reverse, shift to neutral, wait for boat to stop moving forward, then shift into reverse.

B. TRIM TABS



The trim tabs are two flat plates, hinged below the water line on the transom at the rear and are raised and lowered hydraulically by using the rocker switches located at the helm (see Fig. 2.8.1).


The trim tabs are used to adjust the sideways listing of the boat due to uneven loading, a strong cross wind or propeller torque. The twisting effect of propeller torque is especially pronounced when running the engine at high horsepower output. To correct the listing, adjust the trim tabs to level the boat. When the boat is level, right to left, the steering effort will be the same for right and left turns.

Lower the trim tabs on the listing (lower) side by pushing the top half of the trim tab switch in onehalf second bursts until the boat is righted. Using both switches to lower both tabs on a sideto-side balanced boat will lower the bow, when on plane, if the rear of the boat is highly loaded. Again, use only short bursts of the trim tab switches to adjust the trim.

When running at cruising speed, the trim tabs should be fully up, unless the rear is heavily loaded.

In heavy following seas or when running in an inlet, best maneuverability is obtained with a bow high attitude. To be sure the tabs are full up, push the bottom halves of the switches for several seconds.

List	Push
	TOP OF BOTH SWITCHES
PORT	TOP OF STARBOARD SWITCH
STARBOARD	TOP OF PORT SWITCH
PORT	BOTTOM OF STARBOARD SWITCH
STARBOARD	BOTTOM OF PORT SWITCH
	PORT STARBOARD PORT



A PROPERLY TRIMMED BOAT:

- Operates at a correct running attitude of a 3 to 5 degree angle to the water (bow slightly up).
- Reduces drag and increases fuel efficiency
- Preserves good forward visibility.
- Increases safety.

Use short bursts of trim tab switches to adjust trim tabs. Holding switches too long at once may cause sudden steering problems. Adjusting one trim tab more than the other will adjust list caused by improper equipment storage, too many people on one side or a strong cross wind.


REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.


C. POWER TRIM UNIT AND GAUGE

The power trim allows the operator to raise and lower the stern drive unit while underway to provide the ideal boat angle (in relation to water surface) for a given load and water condition (Fig. 2.12.2).

Trimming UP rotates the stern drive and propeller away from the transom. Trimming DOWN rotates the stern drive and propeller closer to the transom.

When the stern drive is trimmed DOWN, the bow of the boat is being forced down. If the trim is in the full DOWN position when accelerating from idle to plane, the boat will plane faster with less bow rise. Once on plane, the stern drive unit can be trimmed UP <u>slightly</u>. This will raise the bow of the boat slightly and increase speed. You will need to try small differences in the stern drive position to determine the trim position you prefer under various conditions.






If you raise the stern drive up too far while you are on plane, you could cause a loss of speed and power due to condition called propeller "ventilation." If this happens, there will be a sudden increase in engine RPM and loss of speed. Do not let this condition exist. Immediately reduce your engine RPM and trim the outdrives DOWN slightly until engine slows down and you regain forward speed.

The trim gauge indicates the position of the stern drive relative to the transom.

REFER TO YOUR ENGINE OPERATOR'S MANUAL FOR PROPER TRIM GAUGE SETTING.



D. TRAILER SWITCH

The trailer switch (power trim switch) (Fig. 2.13.1) is not to be confused with the power trim function. The trailer switch is to be used only when the engine is OFF.

The trailer switch allows the drive unit to be raised for trailering, beaching and launching. To operate, press and hold the trailer switch until the drive unit reaches the end of upward travel. The mechanism that raises the lower unit will stop operating at the end of the upward travel. To bring the drive unit down into boating position, push the power trim switch down.

E. Engine Alarm System

A CAUTION

Always check oil pressure and water gauges while moving, even if your engine has an alarm.

Shut down engine immediately if gauges are not in normal ranges, or alarm sounds.


Do not restart engine until problems are corrected.

The engine Operator's Manual will tell you if your engine is equipped with an audible alarm and how to use it.

The alarm indicates a problem with engine water temperature, oil pressure and/or stern drive oil level.

9. Important Gauges

A. SMARTCRAFTTM GAUGE SYSTEM



Your boat is equipped with the SmartCraft[™] instrumentation system. The SmartCraft[™] system consists of a smart tachometer with a display screen.

The SmartCraft™ system provides a wide range of engine, boat systems and environmental information to the boat operator to help make your time on the water more enjoyable by providing accurate systems information in one convenient location, right at the helm. Below is a list of features the SmartCraft™ system offers.


Refer to the SmartCraft[™] owner's manual in the owner's packet for all SmartCraft[™] operating instructions.

SOME FEATURES INCLUDE:

(Depending on engine type and software version)

System Tach Display Screen:

- Depth/Water Temperature
- Engine Alarm/Hourmeter
- Fuel Consumption/Usage
- Trim Level
- Troll Control
- Voltage
- · Digital Speed



B. TACHOMETER


The tachometer indicates the revolutions per minute (RPM) of the engine. (It does not indicate the speed of the boat.) Your Engine Operator's Manual indicates the maximum full throttle RPM at which your engine should operate. This must not be exceeded or serious engine damage will occur. The tachometer should also be used to determine the most comfortable and economical cruising RPM.

C. OIL PRESSURE, WATER TEMPERATURE, SPEEDOMETER AND FUEL GAUGES

These gauges function on your boat the same way they do on your car or truck. You must continually check these gauges visually to make certain there are no engine system problems even if your boat engine has an alarm system.

D. MAGNETIC COMPASS

Your compass, properly corrected, will indicate magnetic north (not true north). A compass must be adjusted by a qualified person. The reason for this is that nearby instruments or objects containing magnets or current-carrying electrical wires will influence the compass reading. This is especially true if you add electronic devices to the helm station.



After your compass has been professionally adjusted. You will be given a deviation card or chart indicating the correction to be applied when laying out a compass course or making navigational calculations. **Keep this correction card or chart at the helm.**

NOTE: The compass adjustment is only good for the equipment arrangement that existed at the time of the adjustment. If you place different equipment or remove equipment from the vicinity of the compass, you cannot rely on the compass reading. The compass must be readjusted by a qualified person after equipment is added or removed from the vicinity of the compass.

NOTE: The compass roses shown on navigational charts have both true north and magnetic north directions superimposed. Make certain you plot course compass directions from the magnetic north compass rose.

When not in use, the compass should be protected from excessive and prolonged sunlight. If your compass becomes sluggish or erratic, it should be serviced by an authorized repair station.

To keep the plexiglass dome free from scratches, remove salt deposits and dust with a damp cloth. An occasional treatment with paste wax will help preserve the dome surface.


REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.


If you are anchored in open water, i.e. where other boats can approach yours, you must display your anchor light (Fig. 2.15.2): a white light that can be seen from all possible directions, i.e. 360 degrees.

Read the "Federal Requirements and Safety Tips for Recreational Boats" provided in your kit.

10. Navigation and Anchor Lights

Navigation lights (Fig. 2.15.1) MUST be on while underway from sunset to sunrise or in conditions of reduced visibility. "Underway" means the boat is not docked or at anchor. Trolling or drifting with engine off is considered "underway" and navigation lights must be used.





THIS PAGE LEFT INTENTIONALLY BLANK

1. Pre-Launch, Launch and Post-Launch Checklist

Listed below are the critical items you must check and do each time you use your boat. It does not list all of the necessary maintenance and service items required to keep your boat running properly. These other items are found in Section 8.

BE	FORE LAUNCH
	Drain plug installed
	Enough fuel for trip
	Float plan given to friend or relative
	Navigation charts for trip
	Weather forecast - safe
In	THE WATER, BEFORE BOARDING PASSENGERS OR STARTING ENGINE
	Equipment stored and balanced
	No gas smell in engine compartment
	Engine oil and steering fluid levels - OK
	Battery switch on
	Bilge pump working
	Bilge blower on
	Radio and navigation equipment functioning
Pa	SSENGERS
	Wearing PFDs
	Seated properly
	Given safety instructions
ST	ARTING ENGINE
	Make sure you have read and understand th

- Make sure you have read and understand the dangers of Carbon Monoxide (CO) information in this manual.
- ☐ Bilge blower on for at least four (4) minutes. Feel to confirm airflow at hull vent on hull side. Inspect

bilge area for visual and odor confirmation that there are no fuel leaks.

- ☐ Gear shift in neutral position. Throttle pumped before starting, if necessary.
- ☐ Oil pressure, engine temperature, voltage OK after starting and warm up.

UNDERWAY

Gradual	acceleration	and	deceleration	and
turning.				

- ☐ Aware of surroundings at all times.
- Operate so as to prevent buildup of Carbon Monoxide (CO)
- Monitor weather
- Use navigational aids in water and on shore
- ☐ Keep passengers safe
- ☐ Check fuel consumption regularly
- Check all gauges frequently

END OF TRIP

	٠. مالم	al	
Equipment	ary	and	storea.

- ☐ Electronic equipment and switches off.
- Battery switch off.
- Notify person who had float plan.
- □ Boat covered properly for trailering, docking or mooring.
- ☐ If boat is pulled from water, drain plug removed.
- ☐ If boat is pulled from water, hull and propeller inspected for damage.

A WARNING

An improper trailer can cause structural damage to the hull.

A damaged hull can be unsafe; it could cause the boat to sink.

Use a trailer that can properly support the boat's weight and shape. Get professional help in picking the right trailer for your boat.

2. Fueling the Boat

A DANGER

NO SMOKING
GASOLINE VAPORS ARE EXPLOSIVE

NOTICE

GASOLINE RECOMMENDATIONS

Minimum octane rating of 87 AKI.

Refer to the engine owner's manual for additional information

A DANGER

Gasoline vapors can explode from static electricity if fueling is not done properly.


Read and understand this section and Section 5 • Fuel System

The fuel fill cap is located on the midship port side of the boat (Fig. 3.2.1). Do not mistake the water tank fill located on the port bow or the waste pump out cap located on the starboard side of the boat, for the gasoline fill cap.

Refer to your engine manual for the proper grade of gasoline.

BEFORE FUELING

- Fuel during daylight hours.
- Tie boat to the dock.
- Shut off engine, bilge blower and all other electrical equipment.
- Shut off gas burning appliances (gas stove, etc.).
- Close all hatches, doors and keep engine compartment closed to prevent gasoline fumes from entering the cabin or cockpit area.
- All passengers must leave the boat, as a precaution.
- There must be no smoking or any flames within 20 feet of the boat, before, during and for at least 5 minutes after fueling is completed.



 Open fuel fill cap and insert hose nozzle into the fuel fill opening. Fuel fill hose nozzle must contact the fuel fill opening BEFORE adding fuel, and throughout the fueling process, to prevent discharge of static electricity.

FILLING THE TANKS

- Check the fill plate label to ensure that fuel is placed ONLY in the fuel tank. The fuel fill plate is located on the midship port side of your boat (Fig. 3.2.1).
- Keep nozzle in contact with fuel fill opening at all times during fueling.
- Listen as tank fills and stop adding fuel before it spills. Fuel must have room for expansion.

AFTER FILLING

- DO NOT wash spilled fuel overboard. Wipe up any spill with rags or paper towels and dispose of them properly on shore.
- Open engine compartment and check for fuel fumes. This is especially important if your boat is equipped with a gasoline engine. Leave compartment open until no odor is apparent. Close compartment.
- If fumes in the engine compartment do not disappear, do not turn on blower or start engine.
 Get help from trained and experienced persons before using the boat.
- Turn on blower for four minutes, then restart engine.
- Assist passengers back into the boat.

3. Boarding

A WARNING

Wet decks are slippery.

You can be seriously injured if you slip and fall.

Wear slip-resistant footwear secured to your feet and hold onto rails or boat structure.

- DO NOT overload the boat.
- Board one person at a time and give assistance as needed.
- Transfer gear and equipment by handing it from a person on the dock to a person on board. You can lose your balance and be injured if you attempt to board while carrying equipment or gear.
- Distribute the weight of equipment and passengers as evenly as possible to keep the boat balanced.
- Stow gear and equipment so that it is accessible, but everything is to be stored in places to prevent it from shifting if the boat encounters rough water or weather.

4. Personal Flotation Devices (PFDs)

- Operator must instruct all passengers on location and use of PFDs (See Section 1-Safety, page 4 for type and usage).
- Children less than sixteen (16) years of age and all nonswimmers, adults as well as children, must wear properly-sized PFDs at all times when aboard.
- ALL passengers should wear PFDs. By the time someone falls overboard, it can be too late for them to put on a PFD and fasten it properly. This is especially true in colder waters, below 70°F, where survival time, before hypothermia sets in, is measured in minutes.
- If there are passengers not wearing PFDs, the PFDs must be readily accessible. "Readily accessible" means out of the storage bag and unbuckled.
- All throwable flotation devices (cushions, rings, etc.) must be right at hand.

5. Passenger Instruction and Location

- Everyone on board must be told about the boat's behavior from starting to getting up on plane.
- Before the operator does any high-speed maneuvers or rapidly accelerates or decelerates the boat, passengers must be warned to sit and hold on and must heed the warning.
- The operator may have to make rapid changes in speed and/or direction to avoid a problem, with little or no time for alerting passengers. It is critical that all passengers be seated in the designated seating areas and holding on at all times to prevent falling overboard or getting knocked about in the boat when underway.
- If standing, maintain a firm grip on handholds.
 When walking, grasp handholds.

6. STARTING THE ENGINE

A DANGER

Gasoline vapors can explode

Before starting the engines, open engine compartment and check for gasoline smell.

 If you smell gasoline, do not start engine; get everyone off the boat and get trained help to find and fix the problem.

If there is no gasoline smell, perform checks specified by manual, then and only then, close engine compartment and run blower for at least 4 minutes before starting.

The engine operation and maintenance manual furnished with your boat describes pre-start and starting procedures. We urge you to thoroughly read and understand your engine manual.

Listed below are basic pre-start and starting reminders. These are not a substitute for the engine manufacturer's specific recommendations.

Open the engine compartment and check for the smell of gasoline.


• IF YOU SMELL GASOLINE, get everyone off the boat, do not operate any electrical switches or light any matches, lighters, etc. Get trained help to find and fix the problem before starting the engine or operating any switches on the boat.



- If you DO NOT smell gasoline...
- Check all fluid levels and any other necessary checks as specified in Section 8 and in the engine manual.



- Check that water level in bilge is minimal. Verify that the bilge pump is operating by turning the bilge pump switch to MANUAL and listening for the pump running and check to see that bilge water is being pumped overboard.
- Close the engine compartment and turn on the battery switch located under the cockpit wet bar.



4. Check fuel level. Be sure you have enough fuel for your trip. Remember the "1/3 Rule": Use no more than 1/3 of your fuel for outbound trip; use 1/3 of the fuel for return trip; keep 1/3 for reserve in case of emergency.




5. Run bilge blowers for at least 4 minutes before attempting to start engine

Unlike your automobile engine which is naturally ventilated even when it is not moving, your boat engine compartment (the bilge) does not have sufficient natural ventilation when the boat is not moving or moving slowly. That is why the engine compartment must have forced ventilation, using the bilge blower, to remove potentially explosive gasoline vapors, before the engine is started and when the boat is moving slowly.


Because it may be difficult to remember to turn on the bilge blower every time you slow down the boat, it is recommended that the bilge blower run all the time when the engines are running.

6. Place drive unit in full DOWN/IN position.



7. Put throttle and shift control lever into neutral; then for a:

COLD ENGINE - Press THROTTLE ONLY button and move shift/throttle lever forward to full open throttle, then return to about 1/4




throttle. In cold weather, it may be necessary to pump lever several times before engine will start.

WARM ENGINE - Press THROTTLE ONLY button and move shift/throttle lever about 1/4 open throttle position. Do not pump lever.

FLOODED ENGINE - Press THROTTLE ONLY button and move shift/throttle lever to full open position. DO NOT pump lever. When the engine starts, move shift/throttle lever back rapidly to decrease engine speed to between 1000 and 1500 RPM.

8. TO START ENGINE:

Turn ignition key clockwise, as in a car, and release when engine starts. Do not crank engine for more than a few seconds if it doesn't start. Engine may be very cold or flooded; see step 7.



- 9. After engine starts, reduce speed to between 1000 and 1500 RPM and check oil pressure.
- 10. If oil pressure is correct, let engine warm up to normal temperature range as specified in the engine manual, before shifting into forward or reverse gear.



IF OIL PRESSURE GOES ABOVE OR BELOW OPERATING RANGE SHUT DOWN THE ENGINE IMMEDIATELY. GET TRAINED HELP TO FIND AND FIX THE PROBLEM.

11. Check water temperature to ensure temperature range remains normal.



IF ENGINE TEMPERATURE GOES ABOVE NORMAL RANGE SHUT DOWN THE ENGINE IMMEDIATELY. GET TRAINED HELP TO FIND AND FIX THE PROBLEM.


7. SHIFTING TO DRIVE THE BOAT

A CAUTION


Cockpit can fill with water if boat is moving forward, when it is put into reverse.

Before shifting into reverse, shift to neutral, wait for the boat to stop moving forward, then shift into reverse.

Bring the shift/throttle lever back to neutral position. The THROTTLE ONLY button will pop out.




Then move shift/throttle lever rapidly, either forward or reverse, but not very far from the neutral position. The drive unit will engage and boat will start to move slowly in either forward or reverse. You can damage the transmission if you




do not shift quickly from neutral into gear. Once clear of the dock, mooring, people and/or the no-wake zone and the boat has been shifted into forward gear, move shift/throttle lever forward to desired engine speed.

8. Stopping the Engine

 Move the shift/throttle lever to NEUTRAL and let engine idle for about 5 minutes to allow engine to cool down.




2. Turn OFF ignition key.



 If you are leaving the boat for more than two hours, turn OFF battery switch.






9. Steering System

A WARNING

Failure of the steering system will cause loss of control of your boat. Any change in steering such as looseness, tightness, binding, etc., must be checked immediately by your Sea Ray dealer.

The steering system is an enclosed push-pull cable that is hydraulically assisted (power steering) at the stern drive end (Fig. 3.6.4 & 3.6.5). THE CABLE AND ITS CONNECTIONS TO THE STEERING WHEEL AND TO THE OUT DRIVE MUST BE INSPECTED AT LEAST TWICE A YEAR BY YOUR SEA RAY DEALER. See Section 8 of this manual for inspection, service and maintenance recommendations.

The power steering pump (Fig. 3.6.5) fluid level MUST be checked every time prior to using the boat. Refer to the steering system information in your Owner's Packet.




10. WINDLASS (OPTIONAL)

The windlass is wired to the 12 volt system through the WINDLASS breaker on the Main DC Breaker Panel located on the cockpit floor storage aft bulkhead.


The windlass facilitates the anchoring of your boat by automatically raising and lowering the anchor. To operate the windlass the WINDLASS power switch on the control station switch panel must be ON.

A. To Operate From the Helm:

- Make sure that the safety lanyard is removed from the anchor chain.
- Turn the WINDLASS MAIN switch ON.
- Push up on the W I N D L A S S CONTROL toggle switch (located below the control station switch panel) to lower the anchor. To raise the anchor, push



down on the WINDLASS CONTROL toggle switch.




NOTICE

It is important that the windlass clutch is tight for proper operation and safety. Periodically check the clutch and tighten if necessary.

To Tighten Clutch: With the anchor in the stowed position, tighten the windlass clutch by inserting the emergency handle into the clutch nut (see Fig. 3.10.1) and turn clockwise.

A WARNING

Keep hands, feet, hair and loose clothing clear of moving parts. Entanglement may cause severe bodily injury (i.e. loss of fingers or toes).




B. To Operate From the Bow:

- Make sure that the safety lanyard is removed from the anchor chain.
- Turn the WINDLASS MAIN switch ON at the control station.
- Lift protective cap on foot switches and depress UP or DOWN switch for the desired result.

C. To Operate Manually:

- Make sure that the safety lanyard (see Fig. 3.7.3) is removed from the anchor chain.
- Insert the emergency handle into the clutch nut (see fig 3.7.4)
- Turn handle clockwise to retrieve anchor.



D. MAINTENANCE:

 Periodically check the motor and control box electrical connections, remove any residue and cover the connections with a small coating of grease.

A DANGER

Make sure that the power is off before any work is performed on the windlass.

It is recommended at least once a year to disassemble the windlass (Fig. 3.8.1) and remove any residue buildup.

- Using the emergency handle, unscrew the clutch nut by turning the handle counterclockwise.
- Remove the drum, upper cone, chain wheel and lower cone.
- Wash down with fresh water and remove any residue.
- Coat contact surfaces with a light film of lubricant.
- Reassemble the unit and tighten clutch by turning the handle clockwise.

REFER TO WINDLASS OPERATOR'S MANUAL IN YOUR OWNER'S PACKET FOR DETAILED OPERATING AND MAINTENANCE INSTRUCTIONS.

1. BILGE

A. FUEL AND OIL SPILLAGE

Regulations prohibit discharging fuel or oily waste in navigable waters. Discharge is defined as any action which causes a film, sheen or discoloration on the water surface, or causes a sludge or emulsion beneath the water surface. A common violation is bilge discharge. Use rags or sponges to soak up fuel or oily waste, then dispose of them properly ashore. If there is much fuel or oil in the bilge, contact a knowledgeable marine service to remove it. Never pump contaminated bilge water overboard.

Fill fuel tank to less than rated capacity. Allow for fuel expansion.




Open the sunpad/engine hatch by pressing the HATCH LIFT switch on the starboard switch pad on the helm.

POWER FAILURE AND COCKPIT/ENGINE HATCH

In the event of power failure the engine hatch can be opened by removing the pin from the top of the electric actuator ram where it attaches to the sunpad/engine hatch and then lifting the hatch. Practice this procedure several times to become familiar with pin locations.

To Manually Lift Sunpad/Engine Hatch:

- 1. Have a 2x4 or similar object ready to prop up the hatch after it is lifted.
- 1. Rase the starboard sunpad cushion and Open actuator access plate.
- 2. Reach inside and feel immediately forward and find the pin.
- 3. Pull pin from actuator ram.
- 4. Manually lift the hatch. Prop up hatch with a 2x4 or similar object.



C. Drain Plug


A DANGER

Install and tighten drain plug before launching boat.

Boat will sink if drain plug is not in place and tight.

The bottom of the engine compartment is called the "bilge". It is the lowest and inner part of the hull. Water and other liquids will collect there.

After removing your boat from the water, unthread the drain plug to drain the bilge (Fig. 4.1.2).



D. BILGE PUMP

WARNING

SINKING HAZARD – Ensure the bilge pumps are operating properly.


A CAUTION

Run bilge pumps in the manual position only as long as necessary to remove water. Running bilge pumps dry can damage the pump motor.

A bilge pump and float switch are located in the bottom of the bilge (Fig. 4.2.1). The bilge pump can be manually activated from the switch located on the Starboard Switch Panel at the helm.

Before starting the engine, push up on the bilge pump switch so that the switch light comes ON. Make sure the pump is working by opening the engine compartment, listening to hear the pump running and checking to see that liquid is being pumped out from the hull discharge (See Fig. 2.9.1). If the bilge has more liquid than normal, see Maintenance Section for locating and correcting the problem.

Except for checking the operation of the bilge pump by using the ON position, leave the switch in the OFF (AUTO) position. In the OFF (AUTO) position, when the bilge liquid is deep enough to activate the float switch, the bilge pump turns on and pumps out the bilge liquid until the float switch drops and shuts off the pump.



If the liquid level in the bilge is higher than normal and the bilge pump empties the bilge when you use the ON switch, either the breaker for the automatic bilge pump circuit has blown or the float switch is not operating properly. Have it checked immediately. If the ON switch does not operate the pump, DO NOT use the boat until the problem is corrected.

The forward emergency high water pump and float switch, located under the cabin entry steps, are wired to the high water alarm. Should the pump be activated by water in the forward bilge, the alarm will sound. If the alarm sounds, immediate attention to the forward bilge area is required.

The bilge pump automatic circuit is protected by a breaker on the main DC breaker panel located on the cockpit floor storage aft bulkhead (See Fig. 6.6.1). The bilge pump manual circuit is protected by a fuse in the accessory fuse block located behind the access panel above the MDP in the STBD storage area.

1. Maintenance

Frequently inspect the area under the float switch to ensure it is free from debris and gummy bilge oil. To clean, soak in heavy duty bilge cleaner for 10 minutes, agitating several times. Check for unrestricted operation of the float. Repeat the cleaning procedure if necessary.

Inspect the bilge pump intake and keep it free of dirt or material which may impede the flow of water through the pump. To clean the pump strainer, depress the lock tabs on both sides of the pump and lift the pump motor.

TROUBLESHOOTING:

If water does not come out of discharge hose:

- 1. Check the "BILGE PUMP" and "FWD SUMP" fuses on the bilge component board (see Fig. 6.4.1) to ensure they have not blown.
- 2. Remove the motor module to see if the impeller rotates with the power on.


- Remove any debris that may have accumulated in the nozzle section or strainer base.
- 4. Check hose and connection on hull side for debris and proper connections.

E. BILGE BLOWER

To prevent buildup of gasoline fumes to the explosive level in the engine compartment, the bilge blower must be run for at least four (4) minutes before starting the engine and kept running at all times when the engine is running to ensure that there will be adequate ventilation when you are moving slowly.




Do not allow obstructions to interfere with bilge blower or ventilation intake operation. Engine performance may be adversely affected.



The bilge blower is protected by a fuse on the accessory fuse block located behind the access panel above the MDP in the STBD storage area (See Fig. 6.3.1).

A WARNING

EXPLOSION/FIRE HAZARD – Run blower at least four (4) minutes before starting engine or generator. Check bilge and engine compartment for fumes.



2. Engine and Stern Drive

A. Maintenance and Service

Engine failure away from shore can be dangerous. You must follow the recommended maintenance schedule to best ensure trouble-free operation of your engine and stern drive.

B. VIBRATION AND CAUSES

Some vibration is to be expected in your boat because of the action of the engines and the propeller. But excessive vibration indicates conditions which must be promptly corrected to avoid damage. The following are some conditions which may cause vibrations:

- Weeds, ropes, fishing lines, nets or your own trailing lines can become wrapped around the propeller and/or shaft, causing vibration and loss of speed. Always stop the boat, make sure it is clear to the rear, and then reverse the propeller after going through a weedy area to unwrap and clear away any weeds which may have accumulated. If this doesn't clear the entanglement, and you can't anchor or moor the boat in shallow water to get to the stern drive in the water, the boat will have to be taken out of the water.
- A badly damaged or distorted propeller or shaft is an obvious cause of vibration. Run at slow speed to shore. REPLACE IMMEDIATELY.
- If the engine mounts fail and the engine can contact the hull while it is running, vibration will be felt. Run at slow speed to shore. REPLACE IMMEDIATELY.

C. IMPACT TO STERN DRIVE

The stern drive can be damaged by impact, either while trailering or boating. To minimize the possibility of impact damage while trailering, keep the stern drive raised to the trailering position.

The hydraulic system used to raise and lower the stern drive can cushion impact and lessen damage from head-on impacts to the stern drive from underwater objects BUT ONLY when the boat is moving forward. There is no protection if the stern drive is struck during reverse operation or from an angle when moving forward.

If you strike a submerged object, STOP THE ENGINE as soon as possible and examine the stern drive unit for damage. Even if no damage is visible, there could be internal problems or difficulty maneuvering. If you must use the boat after impact, run at the lowest speed possible.

D. Propeller Selection

IMPORTANT: Installed propeller must allow engine to operate at its specified maximum WOT (wide open throttle) RPM. Use an accurate service tachometer to verify engine operating RPM.

It is the responsibility of the boat manufacturer and/or the selling dealer to equip the power package with the correct propeller. Refer to Quicksilver publication - Everything You Need To Know About Propellers P/N 90-8614492. Specified engine WOT and operating RPM range are listed in the Mercury MerCruiser Operation, Maintenance and Warranty Manual attached to the engine.

If full throttle operation is below the recommended range, the propeller must be changed to prevent loss of performance and possible engine damage. On the other hand, operating an engine above the recommended operating RPM range will cause higher than normal wear and/or damage.

After initial propeller selection, the following common problems may require that the propeller be changed to a lower pitch:

- Warmer weather and greater humidity cause an RPM loss.
- Operating in a higher elevation causes an RPM loss.
- Operating with increased load (additional passengers, pulling skiers, etc.).

For better acceleration, such as is needed for water skiing, use the next lower pitch propeller. However, do NOT operate at full throttle when using the lower pitch propeller but not pulling skiers.

Because of the many variables of boat design, only testing will determine the best propeller for a particular application. Available propellers are listed in the *Mercury Precision Parts / Quicksilver Accessories Guide*.

A WARNING


If engine is started during propeller maintenance, serious personal injury can occur.

Shut off engine, remove key, shift into neutral, and put tape over ignition switch key slot.

E. Propeller Removal and Installation


A WARNING

Place a block of wood between the anti-ventilation plate and propeller to protect hands from propeller blades and to prevent propeller from turning when tightening propeller nut.




SINGLE PROPELLER DRIVE UNITS:

1. Shut off engine, remove key, shift into neutral and put tape over ignition switch key slot.




2. Straighten the bent tabs on the propeller nut retainer (Figure 4.5.2).

- 3. Remove the propeller nut retainer, the thrust hub and the continuity washer (Figure 4.5.3) and put them in a secure place. Pull the propeller straight off the shaft. Remove the thrust washer that is behind the propeller. If the propeller is seized to the shaft and cannot be removed by hand, special tools are needed. Have the propeller removed by an authorized dealer or trained mechanic.
- 4. Coat the propeller shaft with an anti-seize lubricant.



- 5. Install the thrust washer, propeller, continuity washer, thrust hub, propeller nut retainer and the propeller nut onto the shaft (Figure 4.5.3).
- 6. Secure the propeller nut by bending three (3) of the tabs of the propeller nut retainer into the thrust hub grooves.




DUAL PROPELLER DRIVE UNIT:

1. Shut off engine, remove key, shift into neutral and put tape over ignition switch key slot.

IMPORTANT: Correct rotation propeller MUST match direction or rotation of propeller shaft.

- Remove Propeller shaft anode and rear prop nut. Pull the propeller straight off the shaft. Remove the rear thrust washer that is behind the rear propeller. If the propeller is seized to the shaft and cannot be removed by hand, special tools are needed. Have the propeller removed by an authorized dealer or trained mechanic.
- 3. Remove the front prop nut, propeller and thrust washer in the same manner.
- 4. Coat the propeller shaft with an anti-seize lubricant.
- 5. Slide front thrust hub onto propeller shaft, with tapered side toward propeller hub.
- 6. Align splines and place front propeller on propeller shaft.
- 7. Install front prop nut and torque. (Refer to drive owners manual for specific torque value.)
- 8. Install rear thrust hub, propeller and nut in same manner.
- 9. Install propeller shaft anode.




3. Underwater Gear

A. Propeller General Information

Propellers should be free of nicks, excessive pitting and any distortions that alter them from their original design. Badly damaged propellers should be replaced, but those that are chipped, bent or merely knocked out of shape can be reconditioned by your marine dealer.

When doing extensive cruising, it is advisable to carry an extra propeller aboard.

BASIC PROPELLER CHARACTERISTICS



Propellers have two basic characteristics:

- Diameter
- Pitch.

Diameter is that distance measured across the propeller hub line from the outer edge of the 360° that is made by the propeller's blade during a single rotation. Pitch is that distance in inches that a propeller will travel if rotated one revolution without any slippage.


For example, a propeller with a 12-inch pitch, when rotated 360° would, theoretically, advance 12 inches through the water. Actually, no propeller applied to any boat is 100% efficient. No 12-inch pitch blade will, in a single rotation, advance a boat 12 inches. This variance is referred to as slippage.

VENTILATION, ITS CAUSES AND CORRECTIONS

While often called "cavitation," ventilation is really a different effect. At times when a boat enters or leaves a sharp turn, the propeller seems to slip and lose thrust and the engine may over-speed. This problem is normally caused by air or aerated water entering the propeller. (A damaged propeller can also cause ventilation.) Ventilation can usually be corrected by one or more of the following:

- 1. Replace the damaged or incorrect propeller with the recommended one.
- 2. With stern drives, set the outdrive at a lesser trim angle (trim the unit downward).

CAVITATION, ITS CAUSES AND CORRECTIONS




Cavitation is a phenomenon that occurs in all propeller-driven craft under certain conditions. The surface of propeller blades are not perfectly flat, and as water is drawn through the blades to be discharged aft into the propeller's slip stream, the water flowing over the curved surface of the blade encounters areas of greater and less pressure.

In those areas of reduced pressure, air bubbles are formed. When they move out of the low pressure area these bubbles collapse. If they collapse while in contact with an object, such as part of the propeller blade or trim plane, the bubbles create such highly localized forces that they erode the surface of the object. In the case of the propeller, such damage is sometimes called a "burn". It may be caused by an irregularity in the propeller's leading edge, and it should be corrected by reconditioning the propeller or by replacement.

Cavitation is a normal occurrence in modern sport boats, and propeller inspection should be part of routine maintenance.

4. BILGE LAYOUT



1. Fuel System

Section 3 - Using Your Boat contains important fueling information. Take time to read all the fuel related information in the Owner's Manual.

The 270 Select EX standard gasoline fuel system consists of a 94 gallon (340.65 liter) fuel tank, fuel tank vent, electric fuel valves, engine fuel supply line and fuel fill (Fig. 5.1.1).

The fuel tank vent serves as a pressure/vacuum release and safety overflow. The fuel vent is located inside the fuel cap on the port side of the deck. Periodically check the vent to assure that it is not clogged.

The fuel pickup at the fuel tank has an electric fuel valve to prevent fuel from siphoning out in the event of fuel line failure.

A CAUTION


Never start an engine until you are certain that fuel fumes are not present in the engine compartment or elsewhere in the boat.

A. ELECTRIC FUEL VALVE

The electric fuel valve (Fig 5.1.1) is wired to the ignition switch. When the ignition is turned ON the valve opens, when the ignition is turned OFF the valve closes. The manual override knob on the side of the valve should be left in the OFF position at all times.

In the event of an electrical malfunction, the valve can be opened and closed manually by turning the manual override knob.

The electric fuel valve is installed in-line on the fuel hose between the fuel tank and the engine.



2. Fueling Precautions

Certain precautions must be carefully and completely observed every time a boat is fueled, even with diesel fuel. Diesel fuel is nonexplosive but it will burn.

A WARNING

CALIFORNIA PROPOSITION 65

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.

A. STATIC ELECTRICITY AND THE FUEL SYSTEM

There is a danger that static electricity can ignite gasoline vapors that have not been ventilated outside an enclosed area. Use extreme caution when fueling your boat from a source outside the regular venues, (e.g. marinas, fuel service stations.)

Your boat has safety features that can be circumvented by not adhering to standard fueling practices. Your boat's bonding system protects it from creating and discharging static electricity.


Your boat must be in contact with the water or a land based grounding system. Here are some helpful suggestions to keep you safe from static electricity while refueling your boat.

- NEVER fuel your boat in unsafe conditions such as: suspended on a sling or in a situation that increases the likelihood of static discharge.
- NEVER use homemade containers to fill your fuel tank.
- Fuel carried onboard outside of a fixed fuel system should be stored in an approved container or in a portable tank such as provided for outboard engines and be stowed safely outside of the engine or living compartments.
- Shutdown the engine, motors and fans prior to taking on fuel. Any ignition sources should be extinguished before filling the fuel tank.
- Close all ports, windows, doors, and hatches.

- Fueling should never be done at night except in well-lighted areas.
- Always keep the fuel nozzle in contact with the fuel fill plate or the edge of the fuel tank opening throughout the filling process.
- Allow areas where gasoline vapors could collect to be ventilated before starting the engine(s).
- Wipe any spillage completely and dispose of rags or waste on shore.
- Secure the fill cap tightly.
- Fuel tank should never be filled to capacity.
 Allow for fuel expansion.
- Portable tanks should only be filled while on the ground; never onboard the boat.

B. GENERAL:

- Check fill plate label to ensure fuel is placed only in fuel tank. Fuel fill plate is located port midship on the deck (Fig. 5.3.1).
- · Avoid spills.
- Know your fuel capacity and consumption.
 Record the amount of fuel used since your last
 fill up, and compute the engine's hourly fuel
 usage. As a fuel gauge backup check, deduct
 the average hourly fuel usage from fuel tank
 capacity.
- Observe the "Rule of Thirds": one-third fuel for trip out, one-third for return and one-third for reserve.
- Allow an additional 15 percent fuel reserve when operating in rough seas.



C. Before and During Fueling Checklist:

- Fire extinguisher close at hand.
- Mooring boat tied securely to fueling pier.
- Crew at least one knowledgeable person present.
- Passengers unnecessary people off the boat.
- Engines stopped.
- Electrical equipment, including blowers power off.
- Windows, doors, hatches closed.
- Smoking material extinguished.
- Inboard tanks grounded.
- Filler pipe marked GAS or DIESEL.
- Fuel nozzle in contact with filler pipe to prevent static sparks.
- Fill level fill less than rated capacity of tank; allow for fuel expansion.
- Trim fuel weight distributed equally.

D. AFTER FUELING CHECKLIST:

- Windows, doors, hatches open.
- Sniff test if fuel fumes remain, operate blowers until fumes are gone.
- Fuel tank secure filler cap.
- Spills wipe; dispose of rags ashore.

THIS PAGE LEFT INTENTIONALLY BLANK

1. DC System

A. DIRECT CURRENT (DC)

The 12 volt direct current (DC) electrical system (similar to that in your car or truck) derives its power from the batteries. Batteries are kept charged by the engine-driven alternator or the optional battery charger/converter which must be powered by shore power. The battery voltage is indicated by the voltmeter on the SmartCraft™ System Tach. The negative terminal of the battery is attached to the main negative bus.

Ask your dealer for a careful analysis of DC power needs on your boat. It may be necessary to add batteries or auxiliary charging methods to supply adequate power for any additional accessories you wish to add.

BATTERIES

A DANGER

DO NOT USE JUMPER CABLES IN THE ENGINE COMPARTMENT.

They can cause an explosion from sparks.

A DANGER

A battery will explode if a flame or spark ignites the free hydrogen given off during charging.

Never use an open flame or strike sparks in the battery area.

The batteries installed in your boat have been selected for their ability to furnish starting power based on engine starting requirements, as well as its ability to power the DC accessories attached to the electrical system. See page 6.2 for the recommended batteries for your boat.

To remove the battery cables:

A CAUTION

To prevent arcing or damage to the alternator, always disconnect battery cables before doing any work on the engine's electrical system.

- 1. Turn off all items drawing power from the battery.
- 2. Turn the battery switch to the OFF position (Battery switch is optional equipment on some models).
- 3. Remove the negative cable first, then the positive cable. To replace the cables, first replace the positive cable, then the negative.

BATTERY MAINTENANCE

- Check the fluid levels in the cells approximately every 4 weeks, and weekly in summer and hot zones.
- The fluid level must be between the lower and upper markings.
- Replenish only with distilled water. Do not use metal funnel.
- Coat battery terminal clamps with silicone grease. Keep batteries clean and dry.


Battery life is shortened if it is drained to zero charge before recharging. It is recommended that a battery not be discharged more than 50 percent. If the battery does become run down, recharge it as soon as possible.

Running the engine to recharge the battery may not be effective. The alternator only creates charging power at higher engine speeds, so simply idling or trolling will not generate enough power to recharge the battery.

If you need to charge a battery, use only a battery charger designed to charge automotive/marine batteries. Use charger only when batteries are disconnected from the boat's electrical circuit. Follow the charger instructions.

If the boat is equipped with dockside power and an AC/DC converter/battery charger, keep it on when shore power is available. This will keep the batteries properly charged and allow use of the DC powered equipment on board without draining the battery.

If your boat will not be used for several weeks or more, and there is no shore power hookup, remove the batteries from the boat and connect them to a charger.



B. RECOMMENDED BATTERIES

The following table describes the recommended marine cranking batteries to install in your boat. All batteries should be of the same type, age & rating.

Application	Group	Volts	CCA*	Reserve	Qty.
Engines	31	12	800	200	2

*COLD CRANKING AMPS

RECOMMENDED BATTERY:


DOUGLAS BATTERY TYPE: 31DCM, ITEM NUMBER: 989 OR EQUIVALENT DIMENSIONS: 13" \times 61 $^{19}/_{16}$ " \times 10 $^{17}/_{16}$ "

C. BATTERY SWITCH

The battery switch controls the delivery of DC power from the batteries to the engine and all equipment, lights and accessories using DC power. The battery switch is located on the main DC breaker panel on the cockpit floor storage aft bulkhead.

NOTE: For safety and convenience the following items are not shut off by the battery switches: bilge pumps, sump pumps, stereo memory, systems monitor and battery charger inputs. These items need constant power to perform their task. This allows the bilge pump to operate any time excess fluid accumulates in the bilge, which can occur

when the boat is docked and unattended. The entire remaining DC system is turned off with the battery switch.



2. Ignition Protection

All electrical components in the engine compartment must be ignition-protected to avoid the possibility of creating sparks in a gasoline environment.

A DANGER

GASOLINE VAPORS CAN EXPLODE

Use ONLY Marine-rated parts to replace such items as starters, distributors, alternators, generators, etc.

Do not use automotive parts for these components or any jumper cables because they are not ignitionprotected and could cause a fire or explosion.

Protective terminal covers, such as rubber boots on electrical connections, must be in place when engine is operating or when working in the engine compartment.

Jumper cables are not ignition-protected. DO NOT USE jumper cables in the engine compartment. The engine compartment may accumulate dangerous explosive gasoline fumes/vapors and hydrogen gas from batteries being charged. A spark produced when connecting a jumper cable can cause an explosion.

3. Fuses

Fuses are located in two areas on your 270 SLX. The accessory fuse block is located behind the access panel above the Main Distribution Panel in the STBD Storage area. The access panel can be removed by removing the four (4) screws that hold it in place. There are also several fuses on the bilge

component board (see Fig. 6.4.1). If you need to replace a fuse, use only the same amperage as the original. It is recommended that you carry spare fuses. See Fig. 6.3.1 and 6.4.1 for the proper fuse sizes.


If a fuse is replaced with one of lower amperage, it will not be sufficient to carry the electrical load of the equipment it is connected to and will cause nuisance fuse failure.

If a fuse or breaker is replaced with one of higher amperage, it will not provide adequate protection against an electrical malfunction and will create a fire hazard.

A WARNING

Use of higher amperage fuses or breakers is a fire hazard.

Use fuses and breakers having the same amperage rating as the original or as specified.




FUSE NAME FUSE AMPERAGE 12VDC 1. HORN 5 2. IGNITION 15 3. NAV LIGHTS 10 4. BILGE BLOWER 7.5 5. WINDSHIELD WIPER 5


5. WINDSHIELD WIPER 5 6. BILGE PUMP 7.5 7. WATER PUMP 10 8. RECEPTACLE 15 9. TRIM TABS 10. LIGHTS 10 11. SPOTLIGHT 15 12. HATCH LIFT 10 13. DOCKING LIGHTS 10 14. REFRIGERATOR 10 15. VHF 10

18. ACCY BLANK
(*REFER TO MANUFACTURER'S RECOMMENDATION FOR FUSE RATING
FOR CHART PLOTTER)

1


2






4. 12 VOLT ACCESSORY RECEPTACLE

Your boat has a 12 volt accessory receptacle in the helm side storage panel and one in the port side storage panel. The receptacle is a cigarette lighter style plug that may be used with any 12 volt accessories using this type of plug.



5. LIGHTING

Your boat is equipped with a variety of different lighting fixtures (See Fig. 6.5.1). Always replace a bulb using the type and wattage of the original bulb.



6. AC System (Optional)

A DANGER

EXTREME HAZARD – Swimming near a boat operating on AC electrical system can lead to severe shock and death. Never swim or allow swimming when AC system is in use.

NOTE: Actual usage of equipment will depend on the amperage output of the power source available.

Line voltage from the shore power is shown by the voltmeter on the main distribution panel. The main breakers may trip if there is a surge in line voltage, an electrical storm or an onboard system overload. The main breaker interrupts both the neutral and hot feeds in the AC circuit to prevent equipment damage due to internal overloads and external surges.

120 Volt / 60 Hz Wiring (Standard System)

A CAUTION

Never operate 120V shore power at less than 110 V.

The 120 volt wiring installed on Sea Ray® boats consists of three (3) color-coded wires. The black wire is the "hot" feed, white is the common, or neutral, and the green wire is the ground. All branch breakers and switches for AC equipment are installed on the "hot" wire. The green conductor of the shore power is connected through the galvanic isolator and then connected to the AC grounding bus bar behind the main distribution panel.

220 Volt / 50 Hz Wiring (Optional System)


A CAUTION

Never operate 220V shore power at less than 208 V.

The 220 volt / 50Hz wiring installed on Sea Ray® boats consists of three (3) color-coded wires. The brown wire is the "hot" feed, light blue is the common, or neutral, and the green wire is the ground. All branch breakers and switches for AC equipment are installed on the "hot" wire. The green conductor of the shore power is connected through the galvanic isolator and then connected to the AC grounding bus bar behind the main distribution panel.

7. Main Distribution Panel Controls and Functions (Optional)

MAIN DISTRIBUTION PANEL (LOCATED IN THE STBD STORAGE AREA) (FIG. 6.6.1)




120 Voit AC Breakers	Amperage	
Main	30	
Outlet	20	
Battery Charger	10	
Accy	Blank	

8. SHORE POWER (OPTIONAL)

A. To Connect and Turn on Shore Power

- 1. On the Boat: Turn OFF All Breakers
- A. Turn OFF equipment breakers
- B. Turn OFF MAIN AC breaker



C. Dry off the shore power cord receptacle on your boat. Dry off the ends of the shore power cord, and spray a moisture repellant into the receptacle and cord ends.

On the boat, plug the cord end into the boat



receptacle. Turn clockwise to lock. Thread the locking ring onto the boat receptacle to prevent accidental unplugging.

A CAUTION

It is imperative that the shore power outlet is dry before plugging into the dock power inlet.

A CAUTION

Route and tie the power cord from the boat to the dockside power outlet box to prevent persons tripping over it and the cord falling in the water.


A CAUTION

Shore power cord should be secured or routed to avoid laying or falling into water and to avoid stress on shore power plug and inlet.

A CAUTION

The use of extension shore power cords is not recommended. Excessive power cord extensions can cause a voltage drop and may prevent some electronic devices from operating correctly.

- 2. On the Dock:
- A. Turn OFF Dock Breaker.
- B. Wipe the outlet dry, spray moisture repellant into the receptacle, then plug the other end of the power cord into the outlet box on the dock.
- C. Turn ON Dock Breaker.



- 3. On the Boat:
- A. Turn ON the main AC breaker on the MDP.



<u>120 Volt or 220 Volt Main Distribution Panel</u> (MDP):

B. POWER Light ON. REVERSE POLARITY Light OFF.

(If reversed polarity light is on do not turn on breakers, turn OFF MAIN and DOCK breakers. Disconnect power cords. Consult dockmaster.)

A CAUTION

Do not energize main breaker under reversed polarity conditions.


Turn ON Breakers:

C. Verify proper voltage.

(120 Volt System: 110V to 125V)


(220 Volt System: 208V to 230V) (International)

D. Turn ON Desired Equipment Breakers.




B. To Disconnect Shore Power


- 1. On the Boat: Turn OFF All Breakers
- A. Turn OFF equipment breakers.
- B. Turn OFF MAIN breaker.



- C. On the dock, turn OFF the dockside breaker.
- D. Disconnect the dockside end of the power cord.



E. On your boat, disconnect the power cord from your boat receptacle.



F. Clean the power cord, spray the cord ends with moisture repellant, and store the cord in a dry location on board.

You must keep the shore power cord and the plug ends clean and dry. This is especially necessary if your boat is used in salt water. Always clean and spray your cord ends with moisture repellant before using and before storing the cord.

C. Maintenance for Shore Power Cable and Shore Power Inlet

A WARNING

Disconnect the power cable from power source before performing maintenance.

The metallic parts of your cable and inlet are made to resist corrosion. In salt water environment, life of the product can be increased by periodically wiping the exposed parts with fresh water, drying and spraying with a moisture repellent.

A soiled cable can be cleaned with grease-cutting household detergent. A periodic application of vinyl protector will help both ends and cable maintain their original appearance.

In case of salt water spray or immersion: Rinse plug end and/or connector end thoroughly in fresh water, shake or blow out excess water and allow to dry. Spray with a moisture repellent before reuse.

9. Servicing the Main Distribution Panel

NOTE: Servicing should be referred to a qualified electrician.

WARNING

Disconnect the power cable from power source before performing maintenance.

A. TO REPLACE A FAULTY COMPONENT ON THE MAIN DISTRIBUTION PANEL:

- 1. Turn all breakers OFF.
- 2. Unplug the shore power.
- 3. Remove screws from all sides except the hinged side of panel. The main distribution panel is hinged to swing open for servicing.
- 4. Reverse the procedure for closing the panel.

10. Battery Charger/Converter (Only With Shore Power Option)

The battery charging unit located on the bilge component board is fully automatic and is designed specifically for the marine environment. The high frequency characteristic has allowed these chargers to achieve a huge size and weight reduction over their previously used equipment. Commonly called high frequency or smart chargers, these units bring a new sophistication to the battery charger field.

A WARNING

Never block air circulation through the unit. Never store any gear on top of the units.

NOTICE

Leave the converter running at all times to maintain the 12 volt system voltage.


Charging characteristics contain four (4) modes:

- Boost Mode this is initiated at power up and provides the chargers full-rated current to the battery bank at a level of 14.4V until battery reaches 90% of full charge.
- Normal Mode this stage immediately follows the bulk charge mode. It maintains the battery voltage at the bulk charge voltage level, but gradually decreases the current as the battery accepts the charge until it reaches a predetermined current level.
- Float Mode this stage is designed to hold the battery at a safe, low voltage (typically 13.2V) providing up to the chargers full rated amperage to accommodate DC load requirements. The charge will remain in this mode until the 12 volt system is activated.
- Equalize Mode this stage activates for 15 minutes every 21 hours. When the converter/ charger is in the float mode the voltage is increased to 14.4 volts which mixes the battery electrolyte to prevent battery stratification.

Note: Leave the charger/converter turned ON at all times to maintain battery voltage level.

Note: Check monthly to ensure that water level in the batteries is properly maintained.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



11. GROUND FAULT INTERRUPTER RECEPTACLE (GFI) (OPTIONAL)

Ground fault interrupter receptacle is located on the Main Distribution Panel. Please read and understand the CAUTION block for GFI receptacles.


A CAUTION

Persons with heart problems or other conditions which make them susceptible to electric shock may still be injured by ground faults on circuits protected by the GFI receptacle. No safety devices yet designed will protect against all hazards or carelessly handled or misused electrical equipment or wiring.

The GFI receptacle is designed to protect people from the line-to-ground shock hazards which could occur from defective power tools or appliances operating from this device, or from down-line outlets protected by it. It does not prevent line-to-ground electric shock, but does limit the time of exposure to a period considered safe for normally healthy persons.

It does not protect persons against line-to-line or line-to-neutral faults.


The GFI receptacle does not protect against short circuits or overloads. This is the function of the circuit breaker.



A. INTERNATIONAL RECEPTACLE

If equipped, all readily accessible 220V outlets are protected by a Residual Current Circuit Breaker (RCCB). This current breaker includes a test switch to verify proper operation. Its function is similar, but not identical to the 120V GFI.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



12. ELECTROLYTIC CORROSION AND ZINC ANODES

Electrolytic corrosion of metals on power boats can result in rapid and serious deterioration of metal parts. You must set a regular schedule and look for the possibility of electrolytic corrosion (the deterioration of metals due to dissimilar characteristics when placed in salt water). It is your responsibility to check for and replace parts damaged due to electrolytic corrosion.

To minimize electrolytic corrosion of the metals on your boat, zinc anode plates are provided on your boat to protect underwater hardware. Zinc, being much less "noble" than the copper-based alloys and aluminum used in underwater fittings, will deteriorate first and protect the other metals.

Stern drives are fitted with zinc anodes on their lower units (refer to your Engine Owner's Manual for their locations). If your boat is equipped with trim tabs, zinc plates are installed on each of the trim tabs.

Zinc anodes require replacement about every six months, if the boat is operated in salt water. In fresh water, the zinc anodes can be replaced about once a year.

If the anodes deteriorate more rapidly than this, there is probably a stray current problem within the boat or at the slip or mooring.

If the anodes do not deteriorate, they are not protecting the other metallic parts of your boat. This can be caused by loose anodes or by low grade zinc or by not having a solid electrical contact between the anode and the metal it contacts, or by paint on the anodes.

If the anodes are deteriorating rapidly, or not at all, contact your dealer.

When an AC shore power system is connected to the boat, the underwater metal fittings will, in effect, be connected through the water to grounded metals ashore. This results in the zincs being consumed at a faster rate unless the marina maintains a protective system to prevent this. When the marina provides a zinc anode in the water bonded to the metal outlet box on the dock, zinc loss on the boat will be reduced. Do not connect this zinc to the boat's ground system.

It is extremely important that all electrically-operated DC equipment and accessories be wired so that the ground polarity of each device is the same as that of the battery. Your boat has a negative ground system. The zinc anode is connected to every metal item in the boat (fuel tanks, underwater gear, etc.) via the green bonding wire.

Galvanic Isolator: Electrolytic corrosion can also be caused by "stray currents" due to a fault in an electrical item, even though correctly grounded. A galvanic current isolator (zinc saver) is standard on all Sea Ray® boats. It is installed between the shore power ground and the boats' AC grounding connection to the DC bonding system. This connection maintains the safety ground from dockside power while stopping the flow of DC corrosive currents. The galvanic isolator is located behind the Main Distribution Panel.

A CAUTION

Never disconnect the green wire (safety ground) from the engine terminal.

NOTICE

DO NOT PAINT BETWEEN THE ZINC AND THE METAL IT CONTACTS, AND DO NOT PAINT OVER THE ZINC.

13. Marine Electronic Cathodic Anti-Corrosion System

The automatically controlled Cathodic Anti-Corrosion System for marine installation protects underwater metals from the effects of corrosion and electrolysis on stern drives. The system components are designed for marine service. DO NOT PAINT THE MERCATHODE® SYSTEM.

The anode and reference electrode are attached to the electrode assembly under each stern drive unit. The solid state controller is mounted within a plastic housing on the transom in the bilge.


Maintenance

The Mercathode® system must be tested to ensure adequate output. The test should be performed every 100 hours or annually. Contact your authorized Sea Ray® dealer to arrange for this test. Refer to the engine operator's manual for more detailed information.


14. ELECTRICAL SCHEMATICS

This owner's manual contains electrical schematics and wiring harness illustrations for your boat. These electrical schematics were generated by electrical CAD designers at the engineering division for technical reference and service technicians. Sea Ray® does not recommend that you attempt to work on the boat's electrical system yourself. Instead, we recommend that you take your boat to your authorized Sea Ray® dealer for service. Sea Ray® reserves the right to change or update the electrical system on any model at any time without notice to the consumer and is NOT obligated to make any updates to units built prior to changes.


270 SLX ELECTRICAL SCHEMATICS












































1. LAYOUT AND ACCESSORY LOCATIONS

Pages 2.6 through 2.8 show the location and arrangement of the most important equipment and components on your boat. Using these drawings, walk through your boat, locate the features shown, and become familiar with their operation and maintenance.

2. WATER SYSTEM

The fresh water system consists of a 21 gallon (79.5 liter) water tank, 12 volt water pump and water system filter.

The fresh water system is activated by the FRESH WATER PUMP switch on the port switch panel at the helm (See Fig. 2.7.2).

To begin initial operation:

- Fill the water tank from a source known to provide safe, pure drinking water by removing the cap marked WATER located on the starboard transom and inserting the water hose nozzle in the opening. Do not mistake the fuel fill or the waste plate for the water tank fill cap.
- 2. Turn ON the FRESH WATER PUMP breaker, located on the Main Distribution Panel.
- 3. Open the sink faucet to allow any air trapped in the water line to dissipate.
- 4. Shut off faucet as flow becomes free of air. Shutting off the faucet will cause the pump to shut off. As long as the water pump and battery switches are on, the pump will automatically provide water on demand.


A. SANITIZING THE WATER SYSTEM

If the fresh water system has not been used for some time, or if you suspect that it has been contaminated, then it should be sanitized. Your marine dealer may have a water treatment additive that can be used to sanitize the system. Follow the instructions provided with the additive.


If a water treatment additive is not available, the following steps may be followed to sanitize the water system:

- 1. Pump the water tank empty. Shut OFF the Fresh Water Pump breaker.
- Determine the capacity of your water tank (your standard water tank holds 21 gallons (79.5 liters)). You will need approximately one (1) gallon of weak bleach solution for each fifteen (15) gallons of tank capacity.
- Prepare the proper amount of a weak bleach solution by mixing 1/4 cup of unscented household chlorine bleach per gallon of water.
- Pour weak bleach solution into the water tank. Remember, use about one (1) gallon of weak bleach solution for each fifteen (15) gallons of tank capacity.
- 5. Fill the remainder of the tank with fresh, clean water. This will further dilute the weak bleach solution.
- Switch ON the Fresh Water Pump breaker, then turn on the faucets and allow the air to be exhausted from the plumbing system. By doing this, the entire fresh water system will be filled with a sanitizing solution.
- 7. Allow the sanitizing solution to stand in the water system for three (3) hours.
- 8. Pump the water tank empty.
- Fill the water system completely with fresh, clean water. Turn on the faucet and permit the entire contents of fresh, clean water to run through the system. This will flush the sanitizing solution out of the plumbing.
- 10. Fill the water system again, with fresh, clean water, and turn on the faucet to permit the air to dissipate.

Your water system is now sanitized.




B. WATER PUMP AND FILTER



The water pump and filter are located on the port side of the engine room above the water heater. The filter prevents particles from entering the pump head. The filter should be checked and cleaned once a season or when flow is restricted.

Before servicing the system, turn the FRESH WATER PUMP breaker OFF and open a faucet to release pressure on the system. To clean the filter, remove the screen and rinse with clean water. Replace, making sure the O-ring is in place when replacing the cover.



C. WINTERIZING THE WATER SYSTEM

For winterizing the water system refer to Section 8, Winterization Checklist For Boats Stored on Land, E. Water System.

D. SHOWER SYSTEM

The shower drains into a self-contained shower sump containing a pump and float switch.


The sump pump is fully automatic and is protected by a fuse on the bilge component board. Check the pump and float switch for obstructions and proper working order.


The pump comes on when there is enough water in the sump to raise the float switch and start the pump. If it does not come on after one or two gallons of water drain from the shower, turn the water off and check the pump and float switch for proper operation.

After using the shower, it is recommended that you run a gallon of clean water through the shower drain to clean out soap residue. Check the pump and float switch for obstructions and proper working order.

E. Fresh Water Washdown

The washdown pullout sprayer is located on the starboard transom. The system uses water from the fresh water tank. The FRESH WATER PUMP breaker must be ON to operate the system.





3. Gray Water System (Option)

The gray water system is designed for boats that are used in areas that restrict overboard water discharge.

The system directs waste water from accessories such as the galley and head sinks and shower to the shower sump that is fitted with a float switch and pump that pumps the water to the head system holding tank. The tank must be emptied when it becomes full.

To empty the head/gray water system holding tank, the services of a dockside pump out station will be needed.

Follow instructions at the station and make sure pump out station hose is inserted into the deck plate marked GRAY WATER/WASTE.

4. HEAD SYSTEM

Several different Toilet (head) systems are available for your boat. The Owner's Manual Packet has specific information on the system installed in your boat. Read that material.

A CAUTION

Do not flush facial tissue, paper towels or sanitary napkins in head. Such material can damage waste disposal system and the environment.

NOTICE

There is a possibility of being fined for having an operable direct overboard discharge in some waters. Close waste discharge seacock and remove handle or take other measures to avoid fine.

A. REQUIREMENTS FOR OPERATORS

The Environmental Protection Agency (EPA) standards state that in freshwater lakes, freshwater reservoirs or other freshwater impoundments whose inlets or outlets are such as to prevent the ingress or egress by vessel traffic subject to this regulation, or in rivers not capable of navigation by interstate vessel traffic subject to this regulation, marine sanitation devices certified by the U.S. Coast Guard installed on all vessels shall be designed and operated to prevent the overboard discharge of sewage, treated or untreated, or of any waste derived from sewage. The EPA standards further state that this shall not be construed to prohibit the carriage of Coast Guard-certified flow-through treatment devices which have been secured so as to prevent such discharges. They also state that waters where a Coast Guard certified marine sanitation device permitting discharge is allowed include coastal waters and estuaries, the Great Lakes and interconnecting waterways, freshwater lakes and impoundments accessible through locks, and other flowing waters that are navigable interstate by vessels subject to this regulation (40 CFR 140.3).

B. PORTABLE HEAD WITH PUMP-OUT

The portable head unit has two individual holding tanks. The top tank is fitted with a hand pump and holds fresh water and chemicals. The bottom tank is for holding waste material (Figure 7.5.1). There is also a dockside pump-out hose attached to the waste material (bottom) tank. The pump-out hose leads to the waste pump-out opening on the starboard side of the boat. To empty the holding tank, the services of a dockside pump-out station are needed. Follow instructions at the station and make sure the pump-out station hose is inserted into the deck plate marked "Waste."


PORTABLE HEAD
(FIG. 7.5.1)

FRESH WATER & CHEMICAL TANK
WASTE MATERIAL TANK

NOTE: Before leaving the dock make sure caps on top and bottom tanks are tight. Make sure top tank is filled with chemicals and the bottom tank is empty.

DETAILED OPERATING INSTRUCTIONS AND WARRANTY INFORMATION ARE PROVIDED BY THE EQUIPMENT MANUFACTURER AND CAN BE FOUND IN THE OWNER'S PACKET.

C. VACUFLUSH® HEAD (OPTION)



The VacuFlush® head utilizes a HEAD SYSTEM breaker on the main distribution panel. The foot pedal at the base of the toilet opens a mechanical seal and vacuum forces waste through the opening in the bowl to an accumulator tank, through the vacuum pump and then

to the holding tank or treatment tank. To Operate:

- 1. Turn ON the WATER PUMP breaker.
- 2. Turn ON the HEAD SYSTEM breaker.


REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

D. HOLDING TANK OPERATION

Waste from the head is directed into the holding tank located in the engine room. The holding tank fluid level indicator is located on the main distribution panel or in the head which indicates 3/4 FULL, FULL and DO NOT FLUSH, or on some models may read FULL, 1/2, or EMPTY. When the FULL light is on, the DO NOT FLUSH light will also be on. When these lights are ON, the holding tank must be emptied before the head can be reused.

DOCKSIDE PUMP-OUT

To empty holding tank, the services of a dockside pump out station will be needed. Follow instructions at the station and make sure pump out station hose is inserted into the deck plate marked WASTE. The holding tank can also be emptied through utilization of the macerator (if supplied) (see *Macerator* in this section).



E. VENT FILTER

The vent filter is designed to control odors associated with the head system operations. The vent filter is located on the holding tank. **The filter must be changed at the beginning of each boating season to be effective.** The vent filter is installed in-line on the holding tank ventilation hose (Fig. 7.6.1).

Note: Do not over fill the holding tank as this will flood the vent filter and render it useless. Filter replacement will then be required. See Parts Manual for correct replacement filter.

5. Entertainment Center

The entertainment center equipment options may vary from boat to boat. Refer to the Owner's Manual Packet to find individual instructions for the equipment installed on your boat.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

A. 12 VOLT STEREO

The 12 volt AM/FM radio single CD satellite ready stereo is located in the port dash.

The system includes six (6) water proof speakers, a subwoofer, a digital remote control located at the control station and an optional remote on the transom. An optional speaker system is available with the Water Sports Tower option.




The stereo is protected by the stereo fuse on the bilge component board. The power source and fuse protection for the stereo memory is on the bilge component board. Power to stereo memory is maintained even if the battery switch is off.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

6. STEERING WHEEL REMOTE CONTROLS

The remote controls on the steering wheel allow the operator to control the stereo system and the SmartCraft™ System View display without reaching for the dash.



The SOURCE buttons group controls the stereo system.

SOURCE button - When pressed and released, powers on the stereo system when it is off. When pressed and released while the system is on cycles between the system sources from radio to satellite to CD player to auxiliary input and back to radio. When pressed and held for one (1) second turns the power off.

UP and DOWN arrow buttons - Control the volume.

LEFT arrow button -

 In radio or satellite mode - When pressed and released cycles through the preset channels. When pressed and held for two (2) seconds in radio mode cycles between AM, FM1, FM2 and FM3 bands; in satellite mode cycles between SAT1, SAT2 and SAT3 bands.

 In CD player mode - When pressed and released skips to the next CD track. When pressed and held for two (2) seconds changes to the next CD in the changer.

RIGHT arrow button -

- In radio or satellite mode When pressed and released cycles through the preset channels. When pressed and held has no effect
- In CD player mode When pressed and released skips to the previous CD track. When pressed and held has no effect.

The SELECT buttons group controls the SmartCraft™ System View display or System Tach and Speedometer.

For Boats with System View:

SELECT button - When pressed and released performs the same function as the SELECT button on the System View. When pressed and held for two (2) seconds performs the same function as the HOME button on the System View.

Direction buttons - When pressed and released perform the same functions as the direction buttons on the System View. When pressed and held have no special function.

For Boats with System Tach and Speedometer:

SELECT button - When pressed and released performs the same function as the MODE button on the System Tach.

Left and Right direction buttons - When pressed and released perform the same functions as the TROLL- and TROLL+ buttons on the System TACH.

Up direction button - When pressed and released selects which system gauge display to control

(Port Tach, Stbd Tach, Speedo). The selected gauge will display reversed text for two (2) seconds. Not Used on single engine boats with one tachometer and no System Speedometer.

Down direction button - Not used

REFER TO THE SMARTCRAFT AND/OR SYSTEM GAUGES OWNER'S MANUAL FOR DETAILED OPERATING INSTRUCTIONS.

7. WATER SPORT TOWER (OPTIONAL)

If equipped, the water sport tower provides a raised attached point (ski tow pylon) for the ski rope. The high attach point enables the skier to perform a wide variety of skills not capable with the lower transom attach point.


The tower attached point is intended for use only when towing a single skier. If you are towing multiple skiers or water toys carrying more than one person use only the transom attached point.

WARNING

DO NOT USE TOWER FOR PULLING INFLATABLES. Use water sports tower for single skier/wakeboarder only. Use ski tow or stern eyes on transom for all other tow behind sports. Heavy loads could collapse tower causing personal injury.

WARNING


DO NOT USE WATER SPORTS TOWER FOR TOWING ANOTHER BOAT OR BEING TOWED. TOWER COULD COLLAPSE AND CAUSE INJURY. SEE OWNERS MANUAL FOR INSTRUCTIONS ON TOWING.



8. FIRE EXTINGUISHER PORT

Boats not equipped with the automatic fire extinguisher option are equipped with a fire extinguisher discharge port. In the event of a fire, a fire extinguisher can be inserted through the port and discharged into the engine compartment without having to open the engine box. Do not open the engine compartment immediately! This feeds oxygen to the fire and flashback could occur.


IF A FIRE OCCURS, IMMEDIATELY SHUT DOWN ALL ENGINES, POWERED VENTILATION, ELECTRICAL SYSTEMS AND EXTINGUISH ALL SMOKING MATERIALS. DO NOT IMMEDIATELY OPEN THE ENGINE COMPARTMENT!! THIS FEEDS OXYGEN TO THE FIRE AND FLASHBACK COULD OCCUR.



MARNING

- In case of fire DO NOT open engine box or compartment.
- · Shut down engine and blowers.
- Continuously discharge entire contents of portable fire extinguisher through port immediately.

9. AUTOMATIC FIRE EXTINGUISHER System (Optional)



Your boat may be equipped with an automatic fire extinguisher system located forward of the engine. In the event of a fire, the heat sensitive automatic head will release the extinguishant as a vapor, totally flooding the area in fire-killing concentrations.

ACTUATION WHEN OCCURS, IMMEDIATELY SHUT DOWN ENGINES. POWERED

VENTILATION. ELECTRICAL SYSTEMS AND EXTINGUISH ALL SMOKING MATERIALS. DO NOT IMMEDIATELY OPEN THE ENGINE COMPARTMENT!! THIS FEEDS OXYGEN TO THE FIRE AND FLASHBACK COULD OCCUR.

Allow the exinguishant to "soak" the compartment for at least fifteen (15) minutes and for hot metals or fuels to cool before cautiously inspecting for cause of damage. Have portable extinguishers at hand and ready. Do not breathe fumes or vapors caused by the fire.

A. Extinguisher Indicator Light

The system indicator light is wired to the ignition and is turned ON when the ignition is turned ON. The indicator light, located on the dash panel, indicates to the helmsman when the unit has discharged. Under normal circumstances, when the ignition is ON the charge indicator light is ON. If the unit discharges, the light will go OFF.

AUTOMATIC FIRE EXTINGUISHER INDICATOR LIGHT (Fig. 7.9.2)


AUTOMATIC HALON SYSTEM

- 1. LIGHT ON-UNIT CHARGED
- 2. LIGHT OFF-UNIT DISCHARGED
 3. IF SYSTEM DISCHARGES. SHUT DOWN ENGINE(S), BLOWERS AND ELECTRICAL SYSTEMS



B. Manual Fire Extinguishing System PULL HANDLE

Located at the control station, the manual fire extinguisher system allows the operator to manually activate the automatic extinguisher in the engine room. Early detection and use of the manual override system will reduce fire damage by eliminating the time necessary for heat in the engine room to rise to a temperature necessary to activate the automatic fire extinguisher.




To Operate:

- 1. Pull pin securing the handle.
- 2. Pull red FIRE handle quickly and briskly.

C. SAFETY PIN

The safety pin is used on boats equipped with the Manual Fire Extinguishing System Pull Handle. The safety pin, located at the neck of the extinguisher bottle in the engine room is for shipping and transfer of the bottle only. The pin MUST be removed in order to manually operate the system.



10. Refrigerator (Optional)

The refrigerator is protected by a fuse on the accessory fuse block located behind the access panel in the STBD storage area.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



Do not cover refrigerator vents.

11. Canvas

A DANGER

If the cockpit is totally enclosed with canvas covers and curtains while the engine is running or boat is moving, carbon monoxide will build up and cause death or permanent injury.

Do not use the rear (aft) curtain while engine is running or boat is moving.

The Bimini Top or sunshade should not be used when the vessel speed exceeds 45 MPH. Damage to the boat or Bimini may occur.

Attached to the inside of the Bimini Top is a DANGER tag for Carbon Monoxide Gas (CO) buildup and a WARNING tag for limiting speeds when Bimini Top canvas is installed. The rear (aft) curtain also has a WARNING tag stating "The Aft Curtain must not be used while engine is running or boat is underway". If your canvas does not have these tags, they become lost or are unable to be read, contact your dealer for replacement labels.

A DANGER

Exhaust fumes from engines contain deadly carbon monoxide gas (CO). Boats enclosed with canvas or with poor ventilation are most likely to collect fumes.

CO sickness symptoms include headache, nausea and dizziness. Do not mistake these symptoms for sea sickness.

Ventilate boat. See Section 1.4, Carbon Monoxide, for more details.

For your safety, decide which canvas pieces you want to remove or install before you leave the boat slip or off-load your boat from the trailer into the water. Removing or installing canvas on the water can be difficult since rough water or wakes can cause you or your passengers to lose their balance while attempting canvas removal or installation.

For safety and ease of installation and removal of canvas, use at least two people. Know which canvas piece(s) that you are to install or remove.

A DANGER

In rainy weather and/or cold weather, fresh air must circulate through boat to avoid carbon monoxide poisoning.

See Section 1.4, Carbon Monoxide, for more details.

The standard canvas consists of a Sunbrella® Bimini Top w/ Boot.


The optional canvas package consists of:

Aft Curtain Canvas Storage Bag

Front Curtains Side Curtains

Cockpit cover w/ Tonneau

The Canvas Cockpit Cover /w Tonneau is also available as an individual option.



A. Installation Tips

- Zippers: Zippers are located on each canvas piece. Make sure canvas is centered over the metal canvas support rods (bows). When attaching any canvas piece, zip the zippers only partially. This helps to hold the piece in place and relieves tension, helping the other sides zip or snap easier. After all the sides of the piece are snapped in place, finish zipping all the zippers. This will ensure a tight fit.
- Adjustable Support Rods: Adjustable support rods are located on the Convertible and Bimini Top. There is an outside tube and an inside tube. Push in the button to adjust for longer or shorter rod lengths.

B. CANVAS CARE AND MAINTENANCE

See Section 9, for instructions on the care and maintenance of your canvas.

12. Horn

The horn is operated by a momentary switch on the dash and is protected by a fuse on the accessory fuse block located behind the access panel in the STBD storage area.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

13. SPOT LIGHT (OPTIONAL)

The spot light is protected by a fuse on the accessory fuse block located behind the access panel in the STBD storage area.

TO OPERATE THE SPOT LIGHT:

- Press the POWER button on the spot light control pad.
- 2. Move the toggle switch to direct the spot light.

REFER TO OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

14. Docking Lights (Optional)

The optional docking lights are protected by a fuse on the Accessory Fuse Block (See Fig. 6.3.1). They are operated by pressing the DOCKING LIGHTS switch on the STBD switch panel at the helm.

THIS PAGE LEFT INTENTIONALLY BLANK

Symbols	Shore Power	
12 Volt Accessory Receptacle 6.4	Electrical System - DC	
12 Volt Accessory Neceptacle 0.4	Accessory Fuse Block	
	Batteries	6.1
	Battery Cable Routing	6.2
В	Battery Switch	6.2
D	Fuses	
Batteries. See Electrical System - DC	Main Distribution Panel	
Battery Charger 6.9	Electrolytic Corrosion	
Bilge	Emergency Situations	
Blower 4.3	Engine	
Hatch 4.1	Maintenance	Q /
Layout 4.8	Maintenance and Service	
Maintenance4.2, 8.4		
Pump 4.2	Starting	
Boarding 3.3	Stopping	
-	Engine Alarm	
Bottom Paint	Entertainment Center	7.6
Breakers & Fuses. <i>See</i> Electrical System Builder's Plate		
	F	
_	Failure: Propulsion, Control or Steering	1.10
C		
Canvas7.10, 9.3	Fiberglass, Care & Cleaning	
Carbon Monoxide	Fire Extinguisher	
Certifications 1.2	Fire Extinguisher Port	
	Fire Extinguisher System	
CE (Common European) markv	Flooding	1.12
NMMA (National Marine Manufacturers Assoc.) . v	Fuel System	
Clearances	Electric Fuel Valve	
Cleats	Fuel Fill	5.3
Compass 2.14	Fuel Gauge	2.7, 2.14
	Fueling	3.2
	Maintenance	8.4
D.	Static Electrical Discharge	5.2
D	Fuses	
Dimensions		
Diving		
Docking		
Docking Lights (Optional)	G	
Dockside Pump-out		
Dockside Pump-out 7.6	Galvanic Isolator	
	Gear Shift and Throttle Control	
	Gelcoat, Care & Cleaning	
E	Gray Water System	7.4
Electrical Schematics		
Electrical System - AC	Н	
GFI Receptacles		
Main Distribution Panel	Hatch, Electric Sunpad/Engine	
RCCB Recepatcle 6.10	Head System	
	Holding Tank	7.5
	Horn	7.11

Hull	Power Capacity 1.6
Identification Number (HIN)iv	Power Trim
Through-Hull Cutouts	Propellers 1.6, 4.4
	Removal and Installation 4.5
	Propulsion System 2.4
I	
Inspection Summary Guide 8.1	R
	Recommended Equipment 1.4
т	Refrigerator 7.10
L	Requirements
Layout	International Requirements 1.13
Bilge 4.8	Required Equipment 1.2
Deck 2.6	
Helm, Gauges & Switches 2.7	
Lighting 6.6	S
Passenger Locations 2.3	3
Lifesaving Equipment 1.4	Safe boating1.1
Lifting 2.1	Safety Labels 1.1
Lights	Service Information 8.3
Exterior 6.6	Service, Summary Guide 8.1
Lights, Navigation and Anchor2.15	Skiing1.9, 7.8
Load Capacity 1.5	SmartCraft™ 2.13
	Spot Light 7.11
	Stability 1.7
N.A.	Stains 9.2
M	Steering System 3.6
Maintenance Log 8.15	Steering Wheel Remote Controls
Maintenance, Summary Guide 8.1	Stern Drive 2.4, 4.4. See also Engine
·	Storage 2.1
	Sump Pump 7.3
	Swimming 1.9
N	Symbols 1.15
Nautical Terms 1.14	System Tach 2.14
	Т
0	
OEMi	Tachometer 2.14. See also Layout: Helm, Gauge &
Oil Pressure 2.14. See also Layout: Helm, Gauge &	Switches
Switches	Trim Tabs 2.11
Owner's Manual Packeti	
_	
P	
Personal Flotation Devices (PFDs) 1.2, 1.4, 3.3	

U	
U.S. Coast Guard (USCG)	
${f V}$	
VacuFlush® Head Visual Distress Signals	
\mathbf{W}	
Warrantiesi	v v
Water Pump	
Water Sport Tower	
Water Sports	
Water System7.1,	
Water Temperature 2.14. See also Layout: He Gauge & Switches	elm,
Weather	1.8
weather	1.0
Windlass	3.7
	3.7
Windlass	3.7

Zinc Anodes 6.11

Index 3

THIS PAGE LEFT INTENTIONALLY BLANK

Section 8 • Required Inspection, Service and Maintenance

Routine inspection, service and maintenance of your boat's systems are vital to assure your safety, as well as for prolonging the life of your boat. You should develop regular routines for inspecting your boat. The chart below summarizes inspection, service and maintenance activities. This section also contains descriptions of some convenient methods for evaluating the condition of some of your boat's systems.

The interval between necessary service or maintenance is highly variable, depending on the environment your boat is in, and on the severity of operating conditions. For example, corrosion of parts on boats operated in salt water proceeds much faster than the corrosion of parts on a boat operated in fresh water. The intervals listed below are recommended maximums, and you must reduce the time between inspections if your observations indicate the need.

1. SUMMARY GUIDE FOR INSPECTION, SERVICE AND MAINTENANCE

MAINTENANCE/SERVICE SOURCE EVERY USE FIRST 25 OR 50 HOURS 50 OR 100 HOURS MOS. OR ANNUALLY Battery Check water level Owner's Manual p. 6.1 Owner's Manual p. 4.1 Bilge Blower Hose connections tight Owner's Manual p. 4.3 Owner's Manual p. 4.1 Canvas Clean Owner's Manual p. 9.2 As Needed Controls Steering Check for proper operation Power steering oil level Engine Manual Found MOS. OR ANNUALLY Owner's Manual p. 4.1 Owner's Manual p. 4.3 To be done by Sea Ray dealer every six months Power steering oil level Engine Manual Found Mos. OR ANNUALLY FIRST 20 HOURS 50 OR 100 HOURS NOS. OR ANNUALLY Owner's Manual p. 4.1 Found Mos. OR ANNUALLY FIRST 20 HOURS FOUND HOUS FOUND HOU				INTERVAL				
Bilge Area Clean and check Owner's Manual p. 4.1 Bilge Blower Hose connections tight Owner's Manual p. 4.3 Bilge Pump Float switch operates freely Owner's Manual p. 4.1 Canvas Clean Owner's Manual p. 9.2 Controls Steering Check for proper operation Power steering oil level Engine Manual Engine Manual Engine Manual Power's Manual p. 9.2 Electrical Connections Check for looseness To be done by Sea Ray dealer every six months inkage and pivot points Engine Manual Power's Manual Powe	ITEM	REQUIRED MAINTENANCE/SERVICE		EVERY	FIRST	25* OR 50	50* OR 100	
Bilge Blower Hose connections tight Owner's Manual p. 4.3 • • • • • • • • • • • • • • • • • • •	Battery	Check water level	Owner's Manual p. 6.1	•	•	•		
Canvas Clean Cle	Bilge Area	Clean and check	Owner's Manual p. 4.1					•
Canvas Clean Owner's Manual p. 9.2 As Needed Controls Steering Check for proper operation Power steering oil level Engine Manual Powe	Bilge Blower	Hose connections tight	Owner's Manual p. 4.3			•		•
Controls Steering Check for proper operation Power steering oil level Engine Manual Engine Manual Electrical Connections Check for looseness To be done by Sea Ray dealer every six months Electrical Connections Check for looseness To be done by Sea Ray dealer annually **GFCI (AC) Outlet Check for operation Owner's Manual p. 6.16 ** Engine Alarm Check Engine Manual ** Cooling System Check for leaks Engine Manual ** Connections with engine running Engine Manual ** Crankcase Clean Engine Manual ** Drive belts Check Engine Manual ** Exhaust System Check for leaks Engine Manual ** Elegine Manual ** Check Engine Manual ** Engine Manual ** Check Engine Manual ** Engine Manual ** Flame Arrestor Clean Engine Manual ** Flame Arrestor Clean Engine Manual ** Flame Filter Replace Engine Manual ** Oil and Filter Replace Engine Manual ** Engine Manual ** Oil and Filter Replace Engine Manual ** Engine Manual ** Check Engine Manual ** Oil Level Check Engine Manual ** Engine Manual ** Fluid level Check Level Engine Manual ** Engine Manual ** Fluid level Check Level Engine Manual ** Engine Manual ** Fluid level Check Level Engine Manual ** Engine Manual ** To be done by Sea Ray dealer every six months ** Deal Check Level Engine Manual ** Deal Check Level Engine Manual ** To be done by Sea Ray dealer every six months ** Deal Check Level Engine Manual ** To be done by Sea Ray dealer every six months Deal Check Level Engine Manual ** Deal Check Level Engine Manual ** To be done by Sea Ray dealer annually To be done by Sea Ray dealer annuales To be done by Sea Ray dealer annuales To be done by Sea Ray dealer	Bilge Pump	Float switch operates freely	Owner's Manual p. 4.1					•
Steering Check for proper operation Power steering oil level Engine Manual Engine Manual Inlinkage and pivot points Electrical Connections Check for looseness To be done by Sea Ray dealer every six months Inlinkage and pivot points To be done by Sea Ray dealer annually Search (AC) Outlet Check for operation Owner's Manual p. 6.16 Search (AC) Outlet Check for operation Owner's Manual p. 6.16 Search (AC) Outlet Check for operation Owner's Manual p. 6.16 Search (AC) Outlet Check for leaks Engine Manual Search (AC) Outlet Check Search (AC) Out	Canvas	Clean	Owner's Manual p. 9.2	As Needed				
Power steering oil level Engine Manual • • • • • • • • • • • • • • • • • • •	Controls							
Gear Shift & Throttle Lubricate. Include all shift Inkage and pivot points Engine Manual • • • • • • • • • • • • • • • • • •	Steering	Check for proper operation		То	be done by S	Sea Ray dea	aler every six	c months
Binkage and pivot points		Power steering oil level	Engine Manual	•				
Connections Check for looseness To be done by Sea Ray dealer annually	Gear Shift & Throttle	Lubricate. Include all shift	Engine Manual		•		•	•
Connections Check for looseness **GFCI (AC) Outlet Check for operation Check Engine Alarm Check Cooling System Check for leaks Engine Manual Connections With engine running Crankcase ventilating system Drive belts Check Engine Manual Exhaust System Check for leaks Engine Manual Exhaust System Clean Engine Manual Engine Manual Exhaust System Check for leaks Engine Manual Engin		linkage and pivot points						
**GFCI (AC) Outlet Check for operation Owner's Manual p. 6.16 Engine Alarm Check Engine Manual Cooling System Check for leaks Engine Manual Connections with engine running Crankcase Clean Engine Manual Drive belts Check Engine Manual Exhaust System Check for leaks Engine Manual Exhaust System Check for leaks Engine Manual Flame Arrestor Clean Engine Manual Fuel Filter Replace Engine Manual Mounts (Fasteners) Tighten Engine Manual Oil and Filter Replace Engine Manual Oil Level Check Engine Manual Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual Engine Manual Stern Brive (With Stern Drive Engine Option) Fluid level Check Engine Manual Engine Manual Check Engine Manual En	Electrical							
Alarm Check Engine Manual • Cooling System Check for leaks Engine Manual • Connections With engine running Crankcase Clean Engine Manual • • • • • • • • • • • • • • • • • • •	Connections	Check for looseness		To	be done by	Sea Ray de	ealer annual	ly
Alarm Check Engine Manual •	**GFCI (AC) Outlet	Check for operation	Owner's Manual p. 6.16					•
Cooling System Check for leaks Engine Manual •	Engine							
Connections with engine running Crankcase Clean Engine Manual Drive belts Check Engine Manual Exhaust System Check for leaks Engine Manual Flame Arrestor Clean Engine Manual Fuel Filter Replace Engine Manual Mounts (Fasteners) Tighten Engine Manual Oil and Filter Replace Engine Manual Oil Level Check Engine Manual Fuel Filter Replace Engine Manual Oil Level Check Engine Manual Fuel Filter Replace Engine Manual Fuel Filter Engine Filter E	Alarm	Check	Engine Manual	•				
Crankcase ventilating system Drive belts Check Engine Manual Exhaust System Check for leaks Engine Manual Exhaust System Check for leaks Engine Manual	Cooling System	Check for leaks	Engine Manual	•				
Ventilating system Check Engine Manual • Drive belts Check Engine Manual • Exhaust System Check for leaks Engine Manual • Flame Arrestor Clean Engine Manual • Fuel Filter Replace Engine Manual • Mounts (Fasteners) Tighten Engine Manual • Oil and Filter Replace Engine Manual • • Oil Level Check Engine Manual • • Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual • •	Connections	with engine running						
Drive belts Check Engine Manual • • Exhaust System Check for leaks Engine Manual • • Flame Arrestor Clean Engine Manual • • Fuel Filter Replace Engine Manual • • Mounts (Fasteners) Tighten Engine Manual • • Oil and Filter Replace Engine Manual • • Oil Level Check Engine Manual • • Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual • •	Crankcase	Clean	Engine Manual		•		•	
Exhaust System Check for leaks Engine Manual • • • • • • • • • • • • • • • • • • •	ventilating system							
Flame Arrestor Clean Engine Manual • • • • • • • • • • • • • • • • • • •	Drive belts	Check	Engine Manual	•				
Fuel Filter Replace Engine Manual • Mounts (Fasteners) Tighten Engine Manual • Oil and Filter Replace Engine Manual • Oil Level Check Engine Manual • Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual •	Exhaust System	Check for leaks	Engine Manual	•	•		•	
Mounts (Fasteners) Tighten Engine Manual • • • • • • • • • • • • • • • • • • •	Flame Arrestor	Clean	Engine Manual		•		•	
Oil and Filter Replace Engine Manual • • • • Oil Level Check Engine Manual • • • • Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual • • • • • • • • • • • • • • • • • • •	Fuel Filter	Replace	Engine Manual				•	
Oil Level Check Engine Manual • Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual •	Mounts (Fasteners)	Tighten	Engine Manual		•			•
Stern Drive (With Stern Drive Engine Option) Fluid level Check level Engine Manual •	Oil and Filter	Replace	•				•	•
Fluid level Check level Engine Manual •	Oil Level	Check	Engine Manual	•				
	Stern Drive (With Stern	Drive Engine Option)						
Fluid Replace Engine Manual •	Fluid level	Check level	Engine Manual	•				
	Fluid	Replace	Engine Manual					•

^{*}Use in salt water or other severe operating conditions requires shorter maintenance/service intervals

^{**}May not be on your boat

Section 8 • Required Inspection, Service and Maintenance

SUMMARY GUIDE FOR INSPECTION, SERVICE AND MAINTENANCE

			INTERVAL				
ITEM	REQUIRED MAINTENANCE/SERVICE	REFERENCE SOURCE	BEFORE EVERY USE	AFTER FIRST 20 HOURS	EVERY 25* OR 50 HOURS	EVERY 50* OR 100 HOURS	EVERY 6 MOS. OR ANNUALLY
Fuel System							
Connections & Lines	Check for leaks	Engine Manual	•	•	•		
Tank	Check for leaks	Owner's Manual p. 5.1	•	•	•		
Water Separating	Replace	Engine Manual		•			•
Fuel Filter							
Sliding Seats and Lad	der						
Helm Seat	Spray slider with light coating of spray lubricant				•		
Transom Swim	Spray slider with light coating				•		
Ladder	of spray lubricant						
Propeller	Inspect for damage		Always after striking object				
Seaworthiness							
Bilge drain plug	Installed and tight	Owner's Manual p. 4.1	•				
Hull damage	Check for loose, damaged		Always after striking object				
Stern drive	or missing parts						
Topside & Supplies	Check for loose, damaged or missing parts	Owner's Manual p. 8.5					•
Anchor rope	Check rope for wear						•
Transmission			•	•	•		
Oil Strainer Screen	Clean		To be done by Sea Ray dealer annually				
Trim Tabs							
Fluid	Check and add as needed	Trim Tab Manual		•			
Zincs							
Transom Zinc	Check and replace as needed	Owner's Manual p. 6.20	Every 25 hours of operation				
Trim Tabs	Check and replace as needed	Trim Tab Manual		Every 25	hours of or	eration	

^{*}Use in salt water or other severe operating conditions requires shorter maintenance/service intervals
**May not be on your boat

2. Useful Service Information

OWNER				
HOME PORT				
BOAT NAME				
REGISTRATION NUMBER			STATE	
HULL SERIAL NUMBER				
WARRANTY REGISTRATION DATE				
ENGINE MAKE & MODEL				
SERIAL NUMBER				
PART NUMBER				
FUEL CAPACITY				
WATER CAPACITY				
KEY NUMBER, IGNITION			DOOR	
SELLING DEALER				
CITY & STATE				
LENGTH	BEAM		DRAFT	
VERTICAL CLEARANCE				
ESTIMATED WEIGHT				
		MODEL #		KII OWATTS

3. Inspection, Service and Maintenance Protocol

A. BILGE AREA

Many of your boat's systems have critical features located in the bilge area. A thorough and organized inspection of the bilge area will address many of these critical features. For example, engine oil leaks and fuel system leaks will show themselves as contamination on the surface of the liquid that remains in the bilge. When you see such contamination, you should look for its source.

Once or twice a year, pump the bilge areas dry and remove all loose dirt. Be sure that all the limber holes are open. Limber holes are the openings in the stringers that allow water to flow from the outboard areas of the bilge to the bilge sump.

Check the bilge pump float switch by moving it manually. (See Fig. 4.1.2) The bilge pump should start when the float switch is raised and should stop when lowered. If it does not, first try resetting the bilge pump breakers, if the pump will still not run replace the float switch before using your boat. The float switch should also move freely without sticking, if it does not, have it serviced or replaced before boating.

A WARNING

DO NOT USE FLAMMABLE SOLVENTS to clean any part of the bilge.

Fumes can accumulate and can be the source of an explosion.

1. OIL

If there is oil contamination, look for leaks in engine oil lines and engine gaskets. If parts of the bilge have been stained by oil, the stain can be removed using a bilge cleaner available from your dealer or a marine store.

2. Engine

Engine failure or malfunction, when away from shore, can be dangerous. Make certain you do the following each time you use the boat:

- Wipe off the engine to remove accumulated dust, grease and oil.
- Check all exposed nuts, bolts and screws for tightness.
- Inspect the belts for wear. If they do not require replacement, check and adjust the belt tension according to the engine manufacturer's recommendation.
- Inspect engine wiring, and clean and tighten the terminals on the engine electrical system.
- Clean and lubricate the battery cables.
- Add distilled water to the battery cells as needed.
- Refer to your Engine Operator's Manual for additional engine maintenance requirements.

3. FUEL SYSTEM

- Inspect the entire fuel system for evidence of leakage, including the fuel tank fill lines and vents. Any stain around a joint could be an indication of a leak.
- Test all fittings with a wrench to be sure they are not loose, but do not forcefully overtighten the fittings.
- Clean fuel filters and vent screens.

WARNING

Work on electrical wiring can create shock hazards or sparks.

Always shut off battery switch, breakers and/or pull fuses before checking electrical wiring or connectors.

4. WIRING SYSTEM

- · Check all wiring for proper support.
- Check all wiring insulation for signs of fraying or chafing.
- Check all terminals for corrosion corroded terminals and connectors should be replaced or thoroughly cleaned.
- Tighten all terminals securely and spray them with light marine preservative oil.

5. FITTINGS, HOSES AND CLAMPS

- Inspect the entire bilge area for evidence of damage or deterioration. Evidence of deterioration will first appear around hull fittings, hoses and clamps.
- Straighten kinked hoses.
- Replace any hose that does not feel pliable.
- Check all hose clamps for tightness and corrosion. Corroded clamps must be replaced.
- Check the nuts, bolts and screws that retain equipment, hoses, etc. in the bilge for tightness and corrosion. Corroded fasteners must be replaced.

B. TOPSIDE AND SUPPLIES

Once a year, you should undertake a thorough review of the topside equipment, as well as of the critical safety supplies on your boat.

- Check cleats, rings, rails, etc. for loose or corroded fasteners, breaks, sharp edges or other conditions that could lead to malfunction or unsafe use. Repair or replace as necessary.
- Inspect PFDs (life jackets) for tears and deterioration.
- Make certain you have enough PFDs on board for the maximum number of persons you can carry.

- Check your first aid kit, making certain it is complete and that the items in it have not passed an expiration date.
- Check the signaling equipment and emergency flares. Make sure all items are within their expiration dates.
- Inspect the anchor, mooring and towing lines.
 Repair or replace as required.
- Check fire extinguishers for full charge.

4. WINTERIZATION CHECKLIST FOR BOATS STORED ON LAND

A. BOAT STORAGE

- Store boat in a bow high attitude.
- Remove hull drain plug.
- Pour one (1) pint (half-liter) of 50% water/ antifreeze mixture in each bilge pump sump.

B. Engines

- Flush engines with fresh water.
- Remove engine drain plugs.

REFER TO YOUR ENGINE OPERATOR'S MANUAL FOR DETAILED INFORMATION ON PREPARING THE ENGINES FOR STORAGE AND WINTERIZATION.

C. BATTERY(IES)

- Remove from boat. Remove the negative (-) cable first, then the positive (+) cable.
- Remove grease and dirt from top surface.
- Grease terminal bolts.
- Store on wooden pallet or thick plastic in a cool dry place. Do not store on concrete.

- Keep under a trickle charge.
- When placing battery back into service, remove excess grease from terminals, recharge as necessary and reinstall in boat.

D. HEAD SYSTEM

- Flush entire system thoroughly with fresh water.
- Pump out holding tank.
- Remove water line from inlet fitting located on back bottom half of water valve on head.
- Flush one gallon (four liters) antifreeze mixed with one gallon (four liters) of water through toilet and let vacuum pump run for one or two minutes.
- Shut FRESH WATER PUMP breaker OFF.
- Pump out holding tank.

E. WATER SYSTEM

- Turn ON the FRESH WATER PUMP breaker.
- Open water faucet, let system drain completely.
- Turn OFF the FRESH WATER PUMP breaker.
- Water must be removed from the water lines with air pressure or flushed with a nontoxic antifreeze.

Using pressurized air to remove water from water lines:

- You must have an air compressor with air hose and air nozzle.
- Remove water hoses from water pump.
- Alternate opening one faucet at a time to make sure water is removed from each line.

• Blow air through the water lines removed from the water pump.

NOTE: When blowing air be careful not to blow air with all faucets closed. System could be damaged by over pressurization and create water leaks.

 Cover hose ends with screen or broad weave cloth and tape in place to keep out dirt and bugs.

USING NONTOXIC WINTERIZING ANTIFREEZE:

- Purchase a nontoxic winterizing antifreeze for fresh water systems from a marine or RV supply retailer.
- With all water pumped out of the system add nontoxic antifreeze to the water tank. Pour in enough to be pumped to all faucets and showers.
- Close all faucets and turn on water system.
- Open one faucet at a time. Close faucet when nontoxic antifreeze comes out of faucet.
- After all faucets and showers have been treated, open all faucets and pump out remaining nontoxic antifreeze.

WATER HEATER WINTERIZATION

 Refer to your water heater Owner's Manual for detailed information on preparing water heater for storage and winterization.

F. FUEL SYSTEMS

GASOLINE:

- Fill fuel tank with gasoline and the recommended amount of stabilizer and conditioner such as "Stabil®".
- Run engine(s) for ten minutes to ensure that all gasoline in the carburetor and fuel lines are treated.

DIESEL

- Fill fuel tank with diesel and recommended amount of biocide, "Biobor®", which prevents bacteria and fungi from contaminating diesel fuel that contains some water.
- Diesel fuel should also get a petroleum distillate additive, such as "Stabil®" or Racor® RX100".
 This will absorb water in the fuel and prevent freezing problems.
- Run engine(s) for ten minutes to ensure that all diesel fuel in injectors and fuel lines is treated.

DETAILED WINTERIZING, OPERATING INSTRUCTIONS AND WARRANTY INFORMATION ARE PROVIDED BY THE EQUIPMENT MANUFACTURER AND CAN BE FOUND IN THE OWNER'S PACKET.

A CAUTION

Do not overfill. Filling a tank until the fuel flows from vents is dangerous. Allow room for expansion.

5. FITTING OUT AFTER STORAGE

A. FUEL SYSTEM

Check the entire fuel system for loose connections, worn hoses, leaks, etc. and repair. This is a primary safety precaution.

Check fuel lines for damage and make sure that they do not come in contact with any moving parts.

B. BATTERY(IES)

Before installing the batteries, clean the terminal posts with a wire brush or steel wool and then attach the cables. After the cable clamps are tightened, smear the post and clamps with vaseline or grease to exclude air and acid. Do not apply grease before

attaching and tightening the terminal clamps. Examine all wiring.

C. MISCELLANEOUS


- Check all thru-hull fittings for unobstructed water passage. Be alert for any deteriorated hoses and/or fittings below the water line which might fail in service and admit water.
- Test the navigation lights.
- Check all wiring for loose connections.
- Check all switches and equipment for proper operation.
- Check bilge blowers for proper operation. Turn ON blowers and place hand over hull blower vent to make sure air is coming from vent.
- Anchor lines and gear should be inspected and replaced if necessary.
- Make sure the hull drain plug is in place and tight.
- Clean bilge thoroughly if it was not done at lay-up.
- Check all engine fluid levels.
- Check fuel lines for damage and/or leaks. Make sure that they do not come into contact with moving parts.

6. SECURITY CONSIDERATIONS

Be conscious of the security of your boat. Always remove the keys from the ignition, lock hatches, lock the cabin door, remove and stow any removable electronic gear (fish finders, GPS, etc.) and personal gear (fishing poles, etc.) normally left aboard your boat.

7. SEACOCK LUBRICATION

- With boat out of water, remove the hose from top of the seacock.
- Put seacock handle in closed position.
- Add a few drops of lubricating oil inside.
- Work handle back and forth a few times. Add oil as needed.
- Replace hose and tighten clamp.
- Add a few drops of oil to the handle pivot point.



8. QUICK REFERENCE CHECKLIST

As the owner/operator of a Sea Ray® boat, you are responsible for the safe operation of your boat and the safety of your passengers. Always be sure that required documents, navigational equipment and Coast Guard required safety equipment is aboard and in proper working order.

A. BOARDING THE BOAT*

-EN	EDAI	Г

	1.	weather Conditions	is it going to be safe to go out
1	2.	Transom Drain Plug	Installed
,		PFDs and all other Coast Guard required safety equipment	Available for all children and adults
	4.	Ignition keys	Available
,	5.	Tool Box	Stocked with a variety of appropriate tools

BOAT SYSTEMS

1.	Bilge Pumps	. Working. Discharge any appreciable amounts of water overboard
2.	Blowers	. Working. "Sniff" the bilge/engine compartment for fuel odor
3.	Navigation Lights	Working. Have spare bulbs (and if applicable fuses) aboard
4.	Radio/Electronics	. Working
5.	Horn	. Working
6.	Trim Tabs	. Full range of motion. No excessive play or binding
7.	Fresh Water Tank	. Filled and sanitized
8.	Head System Holding Tank	. Empty

9. Seacocks Engines & Generator Open (handle parallel to hose),

perpendicular to hose)

Head System Holding Tank Closed (handle

ENGINE

1.	Batteries	. Fully charged (Check water cell levels)
2.	Fuel Tank	. Filled with recommended fuel
3.	Fuel System	. Check for leaks
4.	Fuel Filters	. Check that filters are clean and tight
5.	Diesel Racor Fuel Filters	. Check that filters are clean, tight and free of water
6.	Engine Coolant Drain Plug	. Secured
7.	Steering Fluid	. Full
8.	Throttle & Gearshift Control Test	. Full range of motion

*Note: Many of these items should be checked before leaving the house.

QUICK REFERENCE CHECKLIST (CONT'D)

B. Preparing to Depart and After Launching

GENERAL

1.	Bilge/Engine Compartment	"Sniff" the bilge/engine compartment for fuel odor. Run the bilge blowers for at least four (4) minutes.
2.	Shore Power Cable	Disconnected from dockside power inlet
3.	Lines, Fenders and Anchor	Ready for use
4.	· · · · · · · · · · · · · · · · · · ·	Instructed in duties for getting underway and fitted for a correct size PFD

In the ON position

ENGINE

• • •	Battory Owitorioo		Ort position
2.	Fuel Valves (Diesel Only)	Open	
3.	Engine AlarmT	Γest.	Should sound after a few seconds

4. Gear Shift & Throttle Control In NEUTRAL and IDLE positions

STARTING THE ENGINE*

1 Battery Switches

		Manual for start-up procedures for your specific engine)
2.	Ignition	Turn master ignition keys on DC distribution panel

1. Gearshift & Throttle Control Shift in NEUTRAL (Refer to your Engine Owner's

IMPORTANT: Do not continue to operate starter for more than 10 seconds without pausing to allow starter motor to cool off for 2 minutes. This also will allow the battery to recover between starting attempts.*

A WARNING

Do not run the engine or generator in an enclosed area, such as a closed boat house, as there is the possibility of buildup and inhaling of carbon monoxide.

^{*}If engine fails to start, refer to the Engine Owner's Manual for further troubleshooting procedures

QUICK REFERENCE CHECKLIST (CONT'D)

C. WHILE UNDERWAY

GENERAL

1. Passengers/Crew Safely seated with PFD's on or immediately accessible

2. Lines, Fenders and Anchor Stowed

BOAT SYSTEMS

1. Trim Tabs Bring boat to "On Plane". Adjust as necessary

2. Navigation Lights On at night or in reduced visibility

ENGINE

1. Tachometer Engines operating in safe RPM range

2. Engine Gauges Continually monitor

3. Engine Operation Check idle and shift. Listen for abnormal noises and

visually check the engine compartment while

underway

D. RETURNING TO PORT

GENERAL

2. Lines and Fenders Ready for use

BOAT SYSTEMS

1. Navigation Lights Turned OFF when secured

2. Anchor Light ON if necessary

3. Bilge/Engine Compartment "Sniff" the bilge/engine compartment for fuel odor.

Run the bilge blowers if necessary. Check for water

in bilge. Run bilge pumps if necessary

ENGINE

1. Throttle & Gearshift Control Bring to IDLE and NEUTRAL positions

QUICK REFERENCE CHECKLIST (CONT'D)

3.	Ignition	. Depress ENGINE STOP switches on the helm switch
		panel when engines are cooled down.

E. SECURING THE BOAT

GENERAL

1. Lines and Fenders Fenders in place, lines tied securely to dock

BOAT SYSTEMS

1. Seacocks Closed (handle perpendicular to hose)

2. Helm Switch Panel All switches in the OFF position

3. Gearshift & Throttle Control In the NEUTRAL and IDLE positions

ENGINE

2. Battery Switch In the OFF position

F. IF THE ENGINE DOES NOT START

No Starter Motor Response

- 1. Check gearshift control lever in the NEUTRAL position
- 2. Check battery condition for sufficient charge
- 3. Check battery cable connections tight and free from corrosion
- 4. Check battery switch in the ON position
- 5. Check starter motor and solenoid connections
- 6. Check ignition switch connections

STARTER MOTOR RESPONDS, BUT NO IGNITION

- 1. Check that fuel tanks are not empty
- 2. Check fuel filters and filter/water separators clean
- 3. Check electrical connections on engine wiring harness and ignition wiring

QUICK REFERENCE CHECKLIST (CONT'D)

G. OPERATING THE GENERATOR

STARTING THE GENERATOR

1.	Generator Seacock	Open
2.	Bilge Blower	Run for at least 4 minutes and any time the generator is running
3.	Depress PREHEAT/ON	Preheat time should not exceed 30 seconds
4.	Depress START/RUN Switch	Depress until generator starts
5.	When the Generator Starts	Release the START switch (only continue holding PREHEAT/ ON for a few seconds)
6.	Load The Generator	Turn ON the generator main breaker on the Main
		Distribution Panel. Turn AC breakers ON

STOPPING THE GENERATOR

1.		Turn AC breakers OFF. Turn OFF the generator main breaker on the Main Distribution Panel
2.	Generator	Let it run a few minutes to cool down
3.	STOP Switch	Depress to stop the generator set

WARNING

Do not run the generator or engines in an enclosed area, such as a closed boat house, as there is the possibility of buildup and inhaling of carbon monoxide.

9. AFTER MARKET EQUIPMENT CHECKLIST

Any safety or operational equipment added to your boat after delivery should be checked for seaworthiness and proper working condition. Use the area below to list any equipment and the proper operating condition of that equipment before getting underway.

Equipment	Proper Operating Condition

10. Maintenance Log

Follow the recommended maintenance listed on pages 1 & 2 of this section and keep a record of this and ALL maintenance performed on your boat. You might want to copy these pages before using them to have blank ones available when these are full.

Date	Maintenance Description	Engine Hours

Maintenance Log (Cont'd)

Date	Maintenance Description	Engine Hours

Your new boat has been designed to provide you with years of enjoyment and satisfaction. In order to maintain the factory new appearance of your boat, we recommend the use of 3M™ Marine's one step Maintenance and Reconditioning Products designed specifically for pleasure boats. Following proper fiberglass maintenance guidelines will help maintain your boat's performance, value, and enjoyment.

1. PAINT CLEANING AGENTS AND OTHER SUBSTANCES

A WARNING

EXPLOSION/FIRE HAZARD

Care and refinishing materials may contain ingredients that are flammable or explosive. Do not use such materials in the bilge

Shut off electrical power and ventilate when using such materials anywhere on the boat or in the cabin.

Do not create sparks or use lighted materials.

Do not use products containing chlorine, phosphates, perfumes and nondegradable ingredients. Consult your marine dealer regarding environmental regulations before painting the hull. Fumes can last for hours, and chemical ingredients can harm people, property and the environment. Common household cleaning agents may cause hazardous reactions. Read and understand directions on all paint, cleaning and polishing materials before using.

2. Fiberglass and Gelcoat

The fiberglass hull, deck and some interior parts consist of a molded shell and exterior gelcoat. The gelcoat is the outer surface, often colored, that presents the shiny smooth appearance associated with fiberglass products. This gelcoat surface is painted or taped in some areas for styling purposes.

Wash the gelcoat and fiberglass regularly with clean, fresh water. Wax gelcoated surfaces to maintain the luster. In northern climates, a waxing at the start and end of the boating season may suffice. In southern climates, an application of wax every three months will be required for adequate protection.

A WARNING

Gelcoat surfaces are slippery when wet.

Always wear nonslip footwear securely fastened to your feet and hold on to rails or the boat structure.

A WARNING

Waxed surfaces are slippery.

Do not wax areas that are usually walked on.

REFER TO THE "3M® ONE STEP MAINTENANCE AND RECONDITIONING PRODUCTS" PAMPHLET IN YOUR OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

A. KEEP BILGE AREA DRY

Water may accumulate in the engine room where it is not able to drain to the bilge pump. Check all areas of the engine room for accumulated water and dry thoroughly. Water left standing may penetrate through the gelcoated surfaces and wick into the fiberglass affecting the life of the product.

3. STAINS AND SCRATCHES

Although gelcoat and painted surfaces are resistant to deep stains, a need for cleaning will occasionally arise. But, the use of some common cleaning agents will permanently discolor or otherwise damage the finish on your boat.

- Do not use abrasive porcelain-cleaning powders. These are too abrasive and contain chlorine and ammonia, either of which will permanently discolor gelcoat and paint.
- Never use nail polish remover (acetone) or any ketone solvents.
- Use diluted household detergents to remove surface soil and stains. Before using a given brand, check to make sure it contains no chlorine or ammonia.
- Alcohol can be used to remove difficult stains.
 But it must be promptly washed off with mild detergent and water.
- Minor scratches and deeper stains that do not penetrate the gelcoat may be removed by light sanding and buffing.

4. PERMANENTLY MOORED OR DOCKED BOATS

If permanently moored in salt water or fresh water, your boat will collect marine growth on its bottom. This will detract from the boat's beauty and greatly affect its performance. There are two methods of preventing this:

 Periodically haul the boat out of the water and scrub the bottom with a bristle brush and a solution of soap and water. Paint the hull below the waterline with a good grade of antifouling paint. DO NOT paint the engine drive surfaces.

NOTE: There are EPA regulations regarding bottom paint application. Consult your Sea Ray® dealer for proper application methods.

5. Care for Bottom Paint

From time to time a slight algae or slime forms on all vessels. The bottom painted portion of the hull can be wiped off with a coarse Turkish towel or a piece of old rug while the boat is in the water. Do not use a stiff or abrasive material to clean the bottom paint.

The bottom paint should be inspected annually. If it needs repainting consult your Sea Ray® dealer.

6. Topside Areas

A. STAINLESS STEEL AND ALLOY FITTINGS

Stainless steel and alloy fittings should be cleaned with soap and water or household glass cleaner. Remove rust spots as soon as possible with a brass, silver or chrome cleaner. Irreversible pitting will develop under rust that remains for any period of time. Never use an abrasive like sandpaper or steel wool on stainless. These may actually cause rust. To help protect the stainless, we recommend the use of a good car wax.

B. SALT CRYSTALS

When instruments are exposed to a saltwater environment, salt crystals may form on the bezel and the plastic covers. These salt crystals should be removed with a soft, damp cloth; never use abrasives or rough, dirty cloths to wipe plastic parts. Mild household detergents or plastic cleaners can be used to keep the instruments bright and clean.

REFER TO THE OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

7. Gauge and Switch Panels

No special care is needed. Just wipe off with a soft, fresh water damp cloth to remove dust or salt. Dry after with chamois or soft cloth. Use of protective chemicals is not required.

NOTE: Do not use any chemicals to clean or protect gauge lenses.

8. ACRYLIC PLASTIC SHEETING (PLASTIC GLASS)

Never use a dry cloth or duster or glass cleaning solutions on acrylic.

To clean acrylic, first flood it with water to wash off as much dirt as possible. Next, use your bare hand, with plenty of water, to feel and dislodge any caked dirt or mud. A soft, grit-free cloth may then be used with a nonabrasive soap or detergent. A soft sponge, kept clean for this purpose, is excellent. Blot dry with a clean damp chamois.

Grease and oil may be removed from acrylic with kerosene, hexane, white (not aviation or ethyl) gasoline or aliphatic naphtha (no aromatic content).

Do not use solvents such as acetone, silicone spray, benzine, carbon tetrachloride, fire extinguisher fluid, dry cleaning fluid or lacquer thinner on acrylic, since they attack the surface.

Remove fine scratches with fine automotive acrylic rubbing and polishing compounds.

9. CANVAS AND CLEAR VINYL

Do not fold or store any of the canvas pieces while wet. All canvas should be rolled or folded when dry and stored in a clean, dry place. For clear vinyl pieces, the recommended methods for storage are rolling or laying down flat. The clear vinyl should never be folded or creased as cracking will result. To protect the clear vinyl from rubbing against itself while rolled or stored flat, place a piece of very soft, nonabrasive cloth between the pieces. If the surface of the clear vinyl becomes scratched, the canvas manufacturer has provided a canvas care sheet located in your Owner's Manual Packet. When storing the rear (aft) curtain, fold the canvas over the clear vinyl window (do not fold clear vinyl), then roll or store flat.

The fabric should be cleaned regularly before substances such as dirt, pollen, etc. are allowed to accumulate on and become embedded in the fabric. The fabric can be cleaned without being removed from the installation. Simply brush off any loose dirt, particles, etc.; hose down and clean with a mild solution of a natural soap in lukewarm water (no more than 100°F, 38°C); rinse thoroughly to remove soap. DO NOT USE DETERGENTS. Allow to completely dry.

Wash and clean vinyl windows with a warm soap solution. Use a soft cloth or sponge and do not scratch the surface.

If you have stubborn cleaning cases, call your dealer for proper procedures. Do not try your own cleaning procedures as they may permanently damage the canvas.

After each use, especially in salt water areas, rinse the canvas completely with fresh cold water. Then let the canvas dry completely before stowing.

All metal components of the canvas should be rinsed with fresh cold water and exposed components wiped dry to maintain appearance and working order.

10. Exterior Upholstery Fabric

Exterior fabrics should be cleaned with a sponge or very soft scrub brush and a mild soap and warm water solution. After scrubbing, rinse with plenty of cold, clean water and allow the fabric to air dry in a well ventilated place, preferably away from direct sunlight.

Mildew can occur if your boat does not have adequate ventilation. Heat alone will not prevent mildew; you must also provide for fresh air circulation.

REFER TO THE OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

11. Interior Upholstery Fabric

Cleaning and maintenance information provided by the material manufacturer, is in your Owner's Manual Packet.

NOTICE

Always clean spots, stains, etc., immediately. Test an unseen area of fabric before cleaning stain, to insure that cleaning material will not cause damage.

REFER TO THE OWNER'S MANUAL PACKET FOR INSTRUCTIONS AND OTHER CLEANING INFORMATION.