

Boat Cover Installation Instructions

Your boat cover is rolled and packaged with the bow end of the cover to the outside. The tag on the bow end is sewn into the *inside* hem of the cover.

Before unrolling your boat cover, please take a moment to review the following **helpful tips** for easy installation:

- VHF antennas and collapsible light poles, if mounted to your boat, should be folded down to the rear.
- It is important that you unroll your cover along the center of your boat leaving ample slack at the bow.
- Zippers should remain closed during installation.



NOTE! *This boat cover is not recommended for trailering.*

TO COVER YOUR BOAT, PROCEED AS FOLLOWS:

STEP 1

Place the bow end of the cover (tag side down) loosely on top of the bow of your boat leaving ample slack for adjustment.

STEP 2

Unroll the cover toward the Hard-Top/T-Top. Lift the roll onto the top. With cover stationary on top, proceed to the aft end of the boat.

STEP 3

Equally space the two support poles (included) into the rod holders located on the T-Top or Hard Top. The support poles are designed specifically to keep weight and pressure off the antennas.



STEP 4

From the aft end, grasp roll and unroll the cover taking care to remain between VHF antennas (if applicable). Continue to unroll the cover toward the stern.

STEP 5

Working from the port and starboard sides, spread the boat cover over the support poles. Locate and open the antenna sleeve. Carefully direct the antennas through the sleeve.

STEP 6

Adjust the cover starting at the bow and attach the sewn-in bow strap to bow eye.

STEP 7

Fasten the hook and loop closure on the antenna sleeve.



Antenna Sleeve
(open position)

STEP 8

From either port or starboard side, tie off one side of the draw rope with a secure knot. Thread draw rope into rope ratchet (included) and tighten.



STEP 9

Attach and adjust the tie down straps.



REINFORCEMENT/REPAIR KIT

For added protection at sharp areas and stress points, a Self-Adhesive Reinforcement/Repair Kit with easy-to-follow instructions is included with your boat cover.

TO REMOVE THE BOAT COVER, UNFASTEN THE HOOK & LOOP ANTENNA SLEEVE AND CAREFULLY SLIDE COVER TOWARD THE STERN TO RELEASE ANTENNAS. PLACE ANTENNAS IN THE UPRIGHT POSITION. FOLD COVER TO THE CENTER FROM BOTH SIDES AND ROLL FROM THE BACK TO THE FRONT. IMPORTANT: ALLOW THE COVER TO DRY THOROUGHLY BEFORE FOLDING FOR STORAGE.